

Roland Drum System V-Pro® series

TD-20K

Owner's Manual

Thank you, and congratulations on your choice of the TD-20K Roland Drum System.

Before using this unit, carefully read the sections entitled: "USING THE UNIT SAFELY" (p. 2) and "IMPORTANT NOTES" (p. 3). These sections provide important information concerning the proper operation of the unit. Additionally, in order to feel assured that you have gained a good grasp of every feature provided by your new unit, Owner's manual should be read in its entirety. The manual should be saved and kept on hand as a convenient reference.



Check the Contents of the Box

- TD-20 (Percussion Sound Module) x 1
- PD-125 (V-Pad) x 3
- CY-15R (V-Cymbal Ride) x 1
- VH-12 (V-Hi-Hat) x 1
- PD-105 (V-Pad) x 2
- Tuning Key x 1
- KD-120 (V-Kick Trigger Pad) x 1
- CY-14C (V-Cymbal Crash) x 2
- TD-20K Owner's Manual (this manual)

* The tuning key is included in the VH-12 package.

* The TD-20 Owner's Manual is included in the TD-20 package.

* This package does not include a kick pedal, a snare stand, and a hi-hat stand. Use with a commercially available kick pedal, snare stand, and hi-hat stand.

Copyright © 2005 ROLAND CORPORATION

All rights reserved.

No part of this publication may be reproduced in any form without the written permission of ROLAND CORPORATION.

USING THE UNIT SAFELY

INSTRUCTIONS FOR THE PREVENTION OF FIRE, ELECTRIC SHOCK, OR INJURY TO PERSONS

About ⚠ WARNING and ⚠ CAUTION Notices

⚠ WARNING	Used for instructions intended to alert the user to the risk of death or severe injury should the unit be used improperly.
⚠ CAUTION	Used for instructions intended to alert the user to the risk of injury or material damage should the unit be used improperly. * Material damage refers to damage or other adverse effects caused with respect to the home and all its furnishings, as well to domestic animals or pets.

About the Symbols

	The ⚠ symbol alerts the user to important instructions or warnings. The specific meaning of the symbol is determined by the design contained within the triangle. In the case of the symbol at left, it is used for general cautions, warnings, or alerts to danger.
	The ⚡ symbol alerts the user to items that must never be carried out (are forbidden). The specific thing that must not be done is indicated by the design contained within the circle. In the case of the symbol at left, it means that the unit must never be disassembled.
	The ● symbol alerts the user to things that must be carried out. The specific thing that must be done is indicated by the design contained within the circle. In the case of the symbol at left, it means that the power-cord plug must be unplugged from the outlet.

ALWAYS OBSERVE THE FOLLOWING

⚠ WARNING

- Before using this unit, make sure to read the instructions below, and the Owner's Manual.
- Do not open or perform any internal modifications on the unit. (The only exception would be where this manual provides specific instructions which should be followed in order to put in place user-installable options.)
- Do not attempt to repair the unit, or replace parts within it (except when this manual provides specific instructions directing you to do so). Refer all servicing to your retailer, the nearest Roland Service Center, or an authorized Roland distributor, as listed on the "Information" page.
- Never use or store the unit in places that are:
 - Subject to temperature extremes (e.g., direct sunlight in an enclosed vehicle, near a heating duct, on top of heat-generating equipment); or are
 - Damp (e.g., baths, washrooms, on wet floors); or are
 - Humid; or are
 - Exposed to rain; or are
 - Dusty; or are
 - Subject to high levels of vibration.
- This unit should be used only with a rack or stand that is recommended by Roland.
- When using the unit with a rack or stand recommended by Roland, the rack or stand must be carefully placed so it is level and sure to remain stable. If not using a rack or stand, you still need to make sure that any location you choose for placing the unit provides a level surface that will properly support the unit, and keep it from wobbling.
- Make sure you always have the unit placed so it is level and sure to remain stable. Never place it on stands that could wobble, or on inclined surfaces.
- Do not allow any objects (e.g., flammable material, coins, pins); or liquids of any kind (water, soft drinks, etc.) to penetrate the unit.

⚠ WARNING

- In households with small children, an adult should provide supervision until the child is capable of following all the rules essential for the safe operation of the unit.
- Protect the unit from strong impact. (Do not drop it!)

⚠ CAUTION

- Try to prevent cords and cables from becoming entangled. Also, all cords and cables should be placed so they are out of the reach of children.
- Never climb on top of, nor place heavy objects on the unit.
- Install only the accessories or parts to the drum stand that are recommended by Roland. Remove only the specified screws during the installation.
- Should you remove screws, tuning bolts, washers, lock bushings, etc., keep them in a safe place out of children's reach, so there is no chance of them being swallowed accidentally.

Important Notes

In addition to the items listed under “USING THE UNIT SAFELY” on page 2, please read and observe the following:

Placement

- Do not expose the unit to direct sunlight, place it near devices that radiate heat, leave it inside an enclosed vehicle, or otherwise subject it to temperature extremes. Excessive heat can deform or discolor the unit.
- When moved from one location to another where the temperature and/or humidity is very different, water droplets (condensation) may form inside the unit. Damage or malfunction may result if you attempt to use the unit in this condition. Therefore, before using the unit, you must allow it to stand for several hours, until the condensation has completely evaporated.
- Do not allow rubber, vinyl, or similar materials to remain on the unit for long periods of time. Such objects can discolor or otherwise harmfully affect the finish.

Maintenance

- For everyday cleaning wipe the unit with a soft, dry cloth or one that has been slightly dampened with water. To remove stubborn dirt, use a cloth impregnated with a mild, non-abrasive detergent. Afterwards, be sure to wipe the unit thoroughly with a soft, dry cloth.
- Never use benzene, thinners, alcohol or solvents of any kind, to avoid the possibility of discoloration and/or deformation.

Additional Precautions

- Brushes (nylon) can be used for brush playing. Do NOT use metal brushes!
- Use a reasonable amount of care when using the unit’s buttons, sliders, or other controls; and when using its jacks and connectors. Rough handling can lead to malfunctions.
- When connecting / disconnecting all cables, grasp the connector itself—never pull on the cable. This way you will avoid causing shorts, or damage to the cable’s internal elements.
- To avoid disturbing your neighbors, try to keep the unit’s volume at reasonable levels. You may prefer to use headphones, so you do not need to be concerned about those around you (especially when it is late at night).
- This instrument is designed to minimize the extraneous sounds produced when it’s played. However, since sound vibrations can be transmitted through floors and walls to a greater degree than expected, take care not to allow these sounds to become a nuisance to neighbors, especially when performing at night and when using headphones.
- When you need to transport the unit, package it in the box (including padding) that it came in, if possible. Otherwise, you will need to use equivalent packaging materials.

MDS-20 (Drum Stand)


Assemble the Drum Stand.



About the Stand, refer to the MDS-20 Owner's Manual.

Caution in Setting Up the Stand

- Do NOT open the legs of the stand more than 135 degrees. The distance between the back Right/Left end legs should NOT be more than 2 m (80 inches), otherwise, the cable (inside the Pipes) could be damaged and/or the stand could tip over.




- Do NOT loosen any bolts other than Hand Knobs except when changing the parts or cables for repairing.

TD-20 (Percussion Sound Module)

Attach the stand holder (included with the drum stand MDS-20) to the TD-20.

Using the screws attached to the bottom panel, attach the holder so the unit is oriented as shown in the diagram.



NOTE

- To attach the stand holder, remove the four 12 mm screws (M5 x 12) from the bottom of the TD-20 and use them. Use of other screws may result in damage to the unit.
- When turning the unit upside-down, get a bunch of newspapers or magazines, and place them under the four corners or at both ends to prevent damage to the buttons and controls. Also, you should try to orient the unit so no buttons or controls get damaged.
- When turning the unit upside-down, handle with care to avoid dropping it, or allowing it to fall or tip over.

VH-12 (V-Hi-Hat)

Mount the VH-12 on a commercially available hi-hat stand.




Refer to the VH-12 Owner's Manual.

After the VH-12 is connected to the TD-20 percussion sound module, the **offset** must be adjusted. For details, read the instructions in the TD-20 and VH-12 Owner's Manuals.


KD-120 (V-Kick Trigger Pad)

Contents of the Package


□ KD-120 Pad




□ Leg x 2



□ Stand




□ Beater



* This package does not include a kick pedal. Use with a commercially available kick pedal installed on the KD-120.

* If a felt beater is used, the felt will wear out. Use a plastic beater.

Component (Parts) Names




* Due to the nature of the materials used in the sensor, changes in room temperature and humid may affect the sensitivity of the sensor.

Setup

Assembling the KD-120

1. Place the KD-120 pad, with the head surface facing downward, on a flat surface such as the floor.
2. Use the included tuning key to loosen and remove the bolts for the brackets on the back of the KD-120 pad.
3. Mount the stand on the brackets so that the output jack for the KD-120 pad faces up. Use the bolts you removed earlier to secure the KD-120 pad to the stand, tightening the bolts with the included tuning key.



* Take care not to pinch your fingers between the KD-120 pad and the stand plate.

4. Adjust the ends of the legs to match the location where you're installing the KD-120. Adjust to use the spike legs when installing on carpeting or other soft surfaces, or the rubber legs when installing on flooring or other hard surfaces. When shipped from the factory, the stand is adjusted for using the rubber legs. If you're using the rubber legs, proceed to step 5 on the next page.


Adjusting for the Spike Legs

1. Loosen the leg nut.
2. Turn the rubber foot to adjust so that the spike portion sticks out from the rubber foot. Adjust the length of the spike to suit the location where installing and the length you prefer.

* The tip of the spike is sharp. Handle it with care.


3. Tighten the nut to secure the rubber foot in place and keep it from loosening.

* When using on flooring, the spike legs may damage the floor. Adjust to use the rubber legs.




Adjusting for the Rubber Legs

1. Loosen the leg nut.
2. Turn the rubber foot to adjust so that the spike portion does not stick out from the rubber foot.
3. Tighten the nut to secure the rubber foot in place and keep it from loosening.




- 5. Loosen the T-bolts for the stand and mount the legs on the stand.**
Install the legs as shown in the figure so that the ends of the legs protrude by about 2 cm.



- 6. Tighten the T-bolts to secure the legs to the stand.**
- 7. Lift the KD-120 and place the stand and the four legs upright.**
- 8. Adjust the angle of the head surface so that it's at a right angle to the floor.**
Use the included tuning key to loosen the bracket bolts you tightened in step 3, and adjust the angle of the KD-120 pad so that the head surface is at a right angle to the floor.
- 9. Attach the included plastic beater on your kick pedal.**
- 10. Mount the kick pedal on the KD-120.**

* Make sure there is about 1 cm of space between the two to keep the kick pedal's chain (or belt) from touching the hoop of the KD-120 pad during play. Also, if the kick pedal has no under-plate, then arrange the stand's plate section at a right angle to the floor.



- 11. Make any fine adjustments necessary and tighten the stand brackets to make sure the KD-120 is secure on the stand.**
Make sure the KD-120's four legs and heel portion of the kick pedal is securely on the floor by loosening the stand's T-bolts and adjusting the length of the legs.


* If the kick pedal has no under-plate, then arrange the stand's plate section at a right angle to the floor.

- 12. Adjust the striking point for the beater.**
Normally the beater's striking point is adjusted to fall at the center of the head. Adjust the striking point so that it doesn't extend beyond the cushion on the back of the head. Moving the striking point closer to the sensor increases the sensitivity, so carry out fine adjustment to suit your preferences.

When Using a Twin (Double Kick) Pedal

With the KD-120, you can also play using a twin (double kick) pedal.

Set this up so that the striking points of the two beaters fall at equal distances to the left and right of the center of the head.



* When using a twin (double kick) pedal, as with a regular pedal, use the included beater or a plastic beater as the beater for the kick pedal.

Head Adjustment


The head tension of the KD-120 can be adjusted.

Adjusting the Head Tension

Use the included tuning key to adjust the tension.

In general, a tension that produces a strike response approximately the same as an acoustic bass drum will be appropriate.

* Head tension that is too loose may not only cause incorrect operation, but may even damage the sensor.



1. Check the current tension of the head.
2. Remove the kick pedal from the KD-120.
3. Loosen the lock nuts on the tuning bolts.
4. Adjust bolt 'a' in the above diagram. Rotate it clockwise to tighten the head tension, or slightly counterclockwise to loosen the tension.

* Fully tightening a tuning bolt at only a single location produces uneven tensioning, which may make it impossible to obtain the proper strike sensitivity and may even result in incorrect operation. Be sure to tighten each tuning bolt a little at a time, as described in the above explanation.

5. Adjust bolt 'b' so that the tension is the same as the tension of 'a'.
6. Next adjust 'c' and 'd', and 'e' and 'f' in the same way.
7. Make sure that the head tension is even, and repeat steps 5 and 6 if you wish to make further adjustments.

* On the KD-120, adjusting the head tension affects only the head response, and does not change the pitch of the sound as it would on an acoustic drum. To adjust the pitch, edit the sound parameters of the TD-20. For details refer to the TD-20 owner's manual.

* The head tension will change as the instrument is used, so you should readjust when necessary.

8. Tighten the lock nuts to prevent loosening of the tuning bolts.
9. Mount the kick pedal on the KD-120.

Head Replacement

When the head should be replaced

The head is an expendable item that eventually will wear out and need to be replaced. Replace the head when the following occurs:

- The head surface is torn
- Slack portions remain in the head even when the head tension is properly adjusted.


Replacement heads (optional): Mesh Head (MH-12)

Replacing the Head

When replacing the head, use the included tuning key.

NOTE

Do not apply excessive force to the sensor and cushion located under the head. Doing so can interfere with accurate detection, and may damage it.




1. Loosen the lock nuts on the tuning bolts.
2. Remove all tuning bolts from the KD-120. Go around and gradually loosen each one in order (by turning it counterclockwise).
3. Remove the hoop.
4. Remove the old head.
5. Place the new head on the shell.
6. Place the hoop onto the head.
7. First lightly tighten bolt 'a' in the above diagram by rotating it clockwise. Then tighten bolt 'b' to about the same force.
8. Now lightly tighten 'c', and then 'd'. Tighten 'e' and 'f' in the same way.
9. Next adjust the tension of the head. Refer to "Adjusting the Head Tension" above.

* Fully tightening a tuning bolt at only a single location produces uneven tensioning, which may make it impossible to obtain the proper strike sensitivity and may even result in incorrect operation. Be sure to tighten each tuning bolt a little at a time, as described in the above explanation.

PD-125/PD-105 (V-Pad)

Component (Parts) Names



The only difference between the PD-125 and the PD-105 is the diameter.

* The figure shows the PD-125.

* Do not apply excessive force to the sensor located below the center of the head of the unit. Doing so can interfere with accurate detection, and may damage it.

* Due to the nature of the materials used in the sensor, changes in room temperature and humid may affect the sensitivity of the sensor.

Setup

Connecting to the Sound Module

Use the internal stereo cable to connect to the MDS-20 drum stand. If you use a monaural cable, rim shots cannot be played. You can play rim shots when the pad is connected to the trigger input shown below.

NOTE

To prevent malfunction and/or damage to speakers or other devices, always turn down the volume, and turn off the power on all devices before making any connections.

Rim-Shot-Capable Trigger Inputs

2 (SNARE), 3-6 (TOM 1-4), 12-15 (AUX 1-4)

Brush-Sweep-Capable Trigger Inputs

2 (SNARE)

Mounting on a Snare Stand


Make sure the snare drum stand you use is designed to firmly hold a 12-inch (PD-125) drum.

NOTE

Be sure to tighten the stand fixing screw to prevent the noise.

Mounting on a Tom Stand

When mounting the PD-125/105 to a tom stand, verify the dimension of the rod. (6.3-12.5 mm)



Adjusting the Head

Adjusting the Head Tension

When adjusting, use the included tuning key.

HINT

On the PD-125/105, adjusting the head tension affects only the head response, and not the pitch of the sound, as it would on an acoustic drum. To adjust the pitch, edit the sound parameters of the TD-20. For details refer to the owner's manual.

Heads MUST BE TUNED BEFORE PLAYING.


Like with an acoustic drum, accurate and equal head tension is needed for correct triggering response.

* Head tension that is too loose may not only cause incorrect operation, but may even damage the sensor.


- 1. Loosen the tuning bolts until a slight gap is produced.**
- 2. Tighten all tuning bolts by fingers, as tightly as you can.**

MEMO

Head tension may change over a period of time, so readjust when necessary.



- 3. Using the tuning key, turn the tuning bolts two full revolutions each, thus tightening them.**
Tighten each tuning bolt one by one, observing the numerical order shown in the figure.



CY-15R/CY-14C (V-Cymbal Ride/Crash)

Contents of the Package

CY-15R (Ride)


- ❑ CY-15R unit
- ❑ Wing nut
- ❑ Felt washer
- ❑ Stopper
- ❑ Cable tie

CY-14C (Crash)


- ❑ CY-14C unit
- ❑ Wing nut
- ❑ Felt washer
- ❑ Stopper
- ❑ Cable tie

Component (Parts) Names


CY-15R (Ride)




Diameter: 15 inches



CY-14C (Crash)



Diameter: 14 inches




* The CY-14C has no BOW/BELL OUTPUT Jack.

Mounting on the Stand


1. Use the included tuning key to tighten the stopper bolt.

The stopper keeps the V-Cymbal from turning, and prevents the cables from catching or getting tangled on the stand.




2. Position the Roland logo on the farther side, as viewed from the performer.

3. Tighten the felt washer and the wing nut to obtain the desired movement.



4. Secure the cables in place with the cable tie, while leaving some slack in the cables to ensure that they are not pulled by the movement of the cymbal units when struck.



* Take care to ensure that the cables do not touch the cymbal units and/or the stand. A cable touching a cymbal unit or a stand may cause double sounding or other incorrect operation.

* Double sounding may occur if the wing nut is loose.

* Do NOT use the washer or felt included with the cymbal mount.



Assemble the TD-20K

Using the built-in connection cables of the MDS-20, connect the pads, cymbals, hi-hat, kick trigger pad, and percussion sound module.

NOTE

To prevent malfunction and/or damage to speakers or other devices, always turn down the volume, and turn off the power on all devices before making any connections.

TD-20 Rear Panel * When connecting the cables, please refer to the marking labels that are attached to both ends of the cables.



- The HI-HAT and RIDE cymbal use two cables each.
- After the VH-12 is connected to the TD-20 percussion sound module, the offset must be adjusted.
- Use trigger inputs AUX1-AUX4 when adding new pads.


* Do not pull or stretch the cables too tight.

Playing Methods

PD-125/PD-105

Head Shots


Hit only the head of the pad. With certain snare sounds, playing position will change the nuance of the sound.



Head

Rim Shots

Strike the head and the rim of the pad simultaneously.




Head
Rim

Cross Stick

Only strike the rim of the pad.

Depending on the instrument assigned to the rim you can play rim shots and/or cross stick sounds.



NOTE


To play the cross stick, be sure that you only strike the rim of the pad. Placing your hand on the head of the pad might prevent the cross stick sound from being played properly.

Change the Nuance of the Rim Shot

With certain snare and tom sounds, slight changes in the way you play rim shots changes the nuance.

Normal Rim Shots (Open Rim Shots)

Strike the head and rim simultaneously.




Head
Rim

Shallow Rim Shots

Simultaneously strike the head near the rim and the rim itself.

The same effect is produced by striking only the rim.

* See the TD-20 owner's manual for more info about which sounds allow this.




Head
Rim

CY-15R/CY-14C

Bow Shot


This is the most common playing method, playing the middle area of the cymbal.



Edge Shot

This playing method involves striking the edge with the shoulder of the stick.

The sound is played when the edge sensor area is struck, as shown in the figure.




Bell Shot (CY-15R Only)

This playing method involves striking the bell.


With the CY-15R, a sound is played when the bell portion is struck, as shown in the figure.

- * *Strike the bell somewhat strongly with the shoulder of the stick.*
- * *On the CY-14C, bell shots are not supported.*



Choke Play

Choking (pinching) the cymbal's edge with the hand immediately after hitting the cymbal makes the sound stop. Choke the location of the edge sensor shown in the figure. If you choke an area where there is no sensor, the sound does not stop.




Positional Sensing

The CY-15R is capable of sensing the point on the bow that is struck. You need to choose a cymbal tone that is compatible with positional sensing.

NOTE

The CY-15R's sound changes when the cymbal is struck at different points only when the cymbal is connected to the RIDE trigger input.



Specifications

KD-120 (V-Kick Trigger Pad)

Pad Size: 12 inches
Dimensions: 490 (W) x 400 (D) x 500 (H) mm
19-5/16 (W) x 15-3/4 (D) x 19-11/16 (H) inches
Weight: 7.7 kg
17 lbs
Accessory: Beater
Option: Mesh Head (MH-12)

PD-125 (V-Pad)

Pad size: 12 inches
Triggers: 2 (Head, Rim)
Dimensions: 330 (W) x 420 (D) x 112 (H) mm
13 (w) x 16-9/16 (D) x 4-7/16 (H) inches
Weight: 2.8 kg
6 lbs 3 oz
Option: Mesh Head (MH-12)

* *The hoop's rubber portion is one component that eventually wears out (the more so if numerous rim shots are performed), and will require replacement. Rim shots may not be performed correctly when the rubber portion is worn out. If this occurs, replace the hoop. Consult Roland Service for more on replacing the hoop.*

PD-105 (V-Pad)

Pad size: 10 inches
Triggers: 2 (Head, Rim)
Dimensions: 280 (W) x 360 (D) x 112 (H) mm
11-1/16 (W) x 14-3/16 (D) x 4-7/16 (H) inches
Weight: 2.3 kg
5 lbs 2 oz
Option: Mesh Head (MH-10)

* *The hoop's rubber portion is one component that eventually wears out (the more so if numerous rim shots are performed), and will require replacement. Rim shots may not be performed correctly when the rubber portion is worn out. If this occurs, replace the hoop. Consult Roland Service for more on replacing the hoop.*

CY-15R (V-Cymbal Ride)

Size: 15 inches
Triggers: 3 (Bow/Bell/Edge)
Connectors: BOW/BELL Output Jack,
BOW/EDGE Output Jack
Dimensions: 376 (W) x 376 (D) x 50 (H) mm
14-13/16 (W) x 14-13/16 (D) x 2 (H) inches
Weight: 1.6 kg
3 lbs 9 oz
Accessories: Wing Nut, Felt Washer, Stopper, Cable Tie

CY-14C (V-Cymbal Crash)

Size: 14 inches
Triggers: 2 (Bow/Edge)
Connector: BOW/EDGE Output Jack
Dimensions: 352 (W) x 352 (D) x 48 (H) mm
13-7/8 (W) x 13-7/8 (D) x 1-15/16 (H) inches
Weight: 1.4 kg
3 lbs 2 oz
Accessories: Wing Nut, Felt Washer, Stopper, Cable Tie

* *In the interest of product improvement, the specifications and/or appearance of this unit are subject to change without prior notice.*



This product complies with the requirements of European Directive 89/336/EEC.

For EU Countries

Information

When you need repair service, call your nearest Roland Service Center or authorized Roland distributor in your country as shown below.

AFRICA

EGYPT

Al Fagner Trading Office
9, EBN Hanny At Asklanya
Street,
ARD El Golf, Heliopolis,
Cairo 11341, EGYPT
TEL: 20-2-417-1828

REUNION

Maison FO - YAM Marcel
25 Rue Jules Hermand,
Chaudron - BP79 97 491
Ste Clotilde Cedex,
REUNION ISLAND
TEL: (0262) 218-429

SOUTH AFRICA

T.O.M.S. Sound & Music
(Pty)Ltd.
2 ASTRON ROAD DENVER
JOHANNESBURG ZA 2195,
SOUTH AFRICA
TEL: (011)417 3400
FAX: (011)417 3462

Paul Bothner(PTY)Ltd.

Royal Cape Park, Unit 24
Londonderry Road, Ottery 7800
Cape Town, SOUTH AFRICA
TEL: (021) 799 4900

ASIA

CHINA

Roland Shanghai Electronics
Co.,Ltd.
5F, No.1500 Pingliang Road
Shanghai 200090, CHINA
TEL: (021) 5580-0800

Roland Shanghai Electronics

Co.,Ltd.
(BEIJING OFFICE)
10F, No.18 3 Section Anhuaxili
Chaoyang District Beijing
100011 CHINA
TEL: (010) 6426-5050

HONG KONG

Tom Lee Music Co., Ltd.
Service Division
22-32 Pun Shan Street, Tsuen
Wan, New Territories,
HONG KONG
TEL: 2415 0911

Parsons Music Ltd.

8th Floor, Railway Plaza, 39
Chatham Road South, T.S.T,
Kowloon, HONG KONG
TEL: 2333 1863

INDIA

Rivera Digitec (India) Pvt. Ltd.
409, Nirman Kendra
Mahalaxmi Flats Compound
Off. Dr. Edwin Moses Road,
Mumbai-400011, INDIA
TEL: (022) 2493 9051

INDONESIA

PT Citra IntiRama
Jl. Cideng Timur No. 15J-150
Jakarta Pusat
INDONESIA
TEL: (021) 6324170

KOREA

Cosmos Corporation
1461-9, Seocho-Dong,
Seocho Ku, Seoul, KOREA
TEL: (02) 3486-8855

MALAYSIA

Roland Asia Pacific Sdn. Bhd.
45-1, Block C2, Jalan PJU 1/39,
Dataran Prima, 47301 Petaling
Java, Selangor, MALAYSIA
TEL: (03) 7805-3263

PHILIPPINES

G.A. Yupangco & Co. Inc.
339 Gil J. Puyat Avenue
Makati, Metro Manila 1200,
PHILIPPINES
TEL: (02) 899 9801

SINGAPORE

SWEET LEE MUSIC
COMPANY PTE. LTD.
150 Sims Drive,
SINGAPORE 387381
TEL: 6846-3676

TAIWAN

ROLAND TAIWAN
ENTERPRISE CO., LTD.
Room 5, 9fl. No. 112 Chung
Shan N.Road Sec.2, Taipei,
TAIWAN, R.O.C.
TEL: (02) 2561 3339

THAILAND

Theera Music Co., Ltd.
330 Soi Verng NakornKasem,
New Road, Sumpantawongse,
Bangkok 10100, THAILAND
TEL: (02) 224-8821

AUSTRALIA/ NEW ZEALAND

AUSTRALIA/ NEW ZEALAND

Roland Corporation
Australia Pty., Ltd.
38 Campbell Avenue
Dee Why West. NSW 2099
AUSTRALIA

For Australia
Tel: (02) 9982 8266
For New Zealand
Tel: (09) 3098 715

CENTRAL/LATIN AMERICA

ARGENTINA

Instrumentos Musicales S.A.
Av. Santa Fe 2055
(1123) Buenos Aires
ARGENTINA
TEL: (011) 4508-2700

BARBADOS

A&B Music Supplies LTD
12 Webster Industrial Park
Wildely, St.Michael, Barbados
TEL: (246)430-1100

BRAZIL

Roland Brasil Ltda.
Rua San Jose, 780 Sala B
Parque Industrial San Jose
Cotia - Sao Paulo - SP, BRAZIL
TEL: (011) 4615 5666

CHILE

Comercial Fancy II S.A.
Rut: 96.919.420-1
Nataniel Cox #739, 4th Floor
Santiago - Centro, CHILE
TEL: (02) 688-9540

COLOMBIA

Centro Musica Ltda.
Cra 43 B No 25 A 41 Bododega 9
Medellin, Colombia
TEL: (574)3812529

COSTA RICA

JUAN Bansbach Instrumentos
Musicales
Ave.1. Calle 11, Apartado
10237,
San Jose, COSTA RICA
TEL: 258-0211

CURACAO

Zeelandia Music Center Inc.
Orionweg 30
Curacao, Netherland Antilles
TEL:(305)5926866

DOMINICAN REPUBLIC

Instrumentos Fernando Gonzalez
Calle Proyecto Central No.3
Ens.La Esperilla
Santo Domingo,
Dominican Republic
TEL:(809) 683 0305

ECUADOR

Mas Musica
Rumichacha 822 y Zaruma
Guayaquil - Ecuador
TEL:(593-4)2302364

EL SALVADOR

OMNI MUSIC
75 Avenida Norte y Final
Alameda Juan Pablo II,
Edificio No.4010 San Salvador,
EL SALVADOR
TEL: 262-0788

GUATEMALA

Casa Instrumental
Calzada Roosevelt 34-01,zona 11
Ciudad de Guatemala
Guatemala
TEL:(502) 599-2888

HONDURAS

Almacen Pajaro Azul S.A. de C.V.
BO.Paz Barahona
3 Ave.11 Calle S.O
San Pedro Sula, Honduras
TEL: (504) 553-2029

MARTINIQUE

Musique & Son
Z.I.Les Mangle
97232 Le Lamantin
Martinique F.W.I.
TEL: 596 596 426860

Gigamusik SARL

10 Rte De La Folie
97200 Fort De France
Martinique F.W.I.
TEL: 596 596 715222

MEXICO

Casa Veerkamp, s.a. de cv.
Av. Toluca No. 323, Col. Olivar
de los Padres 01780 Mexico
D.F. MEXICO
TEL: (55) 5668-6699

NICARAGUA

Bansbach Instrumentos
Musicales Nicaragua
Altamira D'Este Calle Principal
de la Farmacia 5ta.Avenida
1 Cuadra al Lago-#503
Managua, Nicaragua
TEL: (505)277-2557

PANAMA

SUPRO MUNDIAL, S.A.
Boulevard Andrews, Albrook,
Panama City, REP. DE
PANAMA
TEL: 315-0101

PARAGUAY

Distribuidora De
Instrumentos Musicales
J.E. Olear y ESQ. Manduvira
Asuncion PARAGUAY
TEL: (595) 21 492147

PERU

Audionet
Distribuciones Musicales SAC
Juan Fanning 530
Miraflores
Lima - Peru
TEL: (51) 4461388

TRINIDAD

AMR Ltd
Ground Floor
Maritime Plaza
Barataria Trinidad W.I.
TEL: (868) 638 6385

URUGUAY

Todo Musica S.A.
Francisco Acuna de Figueroa
1771
C.P.: 11.800
Montevideo, URUGUAY
TEL: (02) 924-2335

VENEZUELA

Instrumentos Musicales
Allegro,C.A.
Av.las industrias edf.Guitar
import
#7 zona Industrial de Turumo
Caracas, Venezuela
TEL: (212) 244-1122

EUROPE

AUSTRIA

Roland Elektronische
Musikinstrumente HmbH.
Austrian Office
Eduard-Bodem-Gasse 8,
A-6020 Innsbruck, AUSTRIA
TEL: (0512) 26 44 260

BELGIUM/FRANCE/ HOLLAND/ LUXEMBOURG

Roland Central Europe N.V.
Houtstraat 3, B-2260, Oevel
(Westerlo) BELGIUM
TEL: (014) 575811

CROATIA

ART-CENTAR
Degenova 3,
HR - 10000 Zagreb
TEL: (1) 466 8493

CZECH REP.

CZECH REPUBLIC
DISTRIBUTOR s.r.o
Voctárova 247/16
CZ - 180 00 PRAHA 8,
CZECH REP.
TEL: (2) 830 20270

DENMARK

Roland Scandinavia A/S
Nordhavnsvej 7, Postbox 880,
DK-2100 Copenhagen
DENMARK
TEL: 3916 6200

FINLAND

Roland Scandinavia As, Filial
Finland
Entonantie 5
FIN-01510 Vantaa, FINLAND
TEL: (09) 68 24 020

GERMANY

Roland Elektronische
Musikinstrumente HmbH.
Oststrasse 96, 22844
Norderstedt, GERMANY
TEL: (040) 52 60990

GREECE/CYPRUS

STOLLAS S.A.
Music Sound Light
155, New National Road
Patras 26442, GREECE
TEL: 2610 435400

HUNGARY

Roland East Europe Ltd.
Warehouse Area "DEPO" Pf.83
H-2046 Torokbalint,
HUNGARY
TEL: (23) 511011

IRELAND

Roland Ireland
G2 Calmount Park, Calmount
Avenue, Dublin 12
Republic of IRELAND
TEL: (01) 4294444

ITALY

Roland Italy S. p. A.
Viale delle Industrie 8,
20020 Arese, Milano, ITALY
TEL: (02) 937-78300

NORWAY

Roland Scandinavia Avd.
Kontor Norge
Lillekerveien 2 Postboks 95
Lilleaker N-0216 Oslo
NORWAY
TEL: 2273 0074

POLAND

ROLAND POLSKA SP. Z O.O.
UL. Gibraltaraska 4.
PL-03 664 Warszawa
POLAND
TEL: (022) 679 4419

PORTUGAL

Roland Iberia, S.L.
Portugal Office
Cais das Pedras, 8/9-1 Dto
4050-465, Porto, PORTUGAL
TEL: 22 608 00 60

ROMANIA

FBS LINES
Piata Libertatii 1,
535500 Gheorgheni,
ROMANIA
TEL: (266) 364 609

RUSSIA

MuTek
Dorozhnaya ul.3,korp.6
117 545 Moscow, RUSSIA
TEL: (095) 981-4967

SLOVAKIA

DAN Acoustic s.r.o.
Pasekova 18,
SK - 940 01 Nové Zámky
TEL: (035) 6424 330

SPAIN

Roland Iberia, S.L.
Paseo Garcia Faria, 33-35
08005 Barcelona SPAIN
TEL: 93 493 91 00

SWEDEN

Roland Scandinavia A/S
SWEDISH SALES OFFICE
Danvik Center 28, 2 tr.
S-131 30 Nacka SWEDEN
TEL: (08) 702 00 20

SWITZERLAND

Roland (Switzerland) AG
Landstrasse 5, Postfach,
CH-4452 Ittingen,
SWITZERLAND
TEL: (061) 927-8383

UKRAINE

EURHYTHMICS Ltd.
P.O.Box: 37-a,
Nedeeby Str. 30
UA - 89600 Mukachevo,
UKRAINE
TEL: (03131) 414-40

UNITED KINGDOM

Roland (U.K.) Ltd.
Atlantic Close, Swansea
Enterprise Park, SWANSEA
SA7 9JF,
UNITED KINGDOM
TEL: (01792) 702701

MIDDLE EAST

BAHRAIN

Moon Stores
No.16, Bab Al Bahrain Avenue,
P.O.Box 247, Manama 304,
State of BAHRAIN
TEL: 17 211 005

IRAN

MOCO INC.
No.41 Nike St., Dr.Shariyati Ave.,
Roberoy Cerah Mirdamad
Tehran, IRAN
TEL: (021) 285-4169

ISRAEL

Halilit P. Greenspoon & Sons
Ltd.
8 Retzif Ha aliya Hashnya St.
Tel-Aviv-Yafo ISRAEL
TEL: (03) 6823666

JORDAN

MUSIC HOUSE CO. LTD.
FREDDY FOR MUSIC
P. O. Box 922846
Amman 11192 JORDAN
TEL: (06) 5692696

KUWAIT

EASA HUSAIN AL-YOUSIFI
& SONS CO.
Abdullah Salem Street,
Safat, KUWAIT
TEL: 243-6399

LEBANON

Chahine S.A.L.
Gerge Zeidan St., Chahine
Bldg., Achrafieh, P.O.Box: 16-
5857
Beirut, LEBANON
TEL: (01) 20-1441

OMAN

TALANTZ CENTRE L.L.C.
Malatan House No.1.
Al Noor Street, Ruwi
SULTANATE OF OMAN
TEL: 2478 3443

QATAR

Al Emadi Co. (Badie Studio &
Stores)
P.O. Box 62, Doha, QATAR
TEL: 4423-554

SAUDI ARABIA

aDawhla Universal
Electronics APL
Corniche Road, Aldossary
Bldg., 1st Floor, Alkhobar,
SAUDI ARABIA

P.O.Box 2154, Alkhobar 31952
SAUDI ARABIA
TEL: (03) 898 2081

SYRIA

Technical Light & Sound
Center
Rawdah, Abdul Qader Jazairi St.
Bldg. No. 21, P.O.BOX 13520,
Damascus, SYRIA
TEL: (011) 223-5384

TURKEY

ZUHAIL DIS TICARET A.S.
Galip Dede Cad. No.37
Beyoglu - Istanbul / TURKEY
TEL: (0212) 249 85 10

U.A.E.

Zak Electronics & Musical
Instruments Co. L.L.C.
Zabeel Road, Al Sherooq Bldg.,
No. 14, Grand Floor, Dubai,
U.A.E.
TEL: (04) 3360715

NORTH AMERICA

CANADA

Roland Canada Ltd.
Toronto Office
(Head Office)
5480 Parkwood Way
Richmond B. C., V6V 2M4
CANADA
TEL: (604) 270 6626

Roland Canada Ltd.

(Toronto Office)
170 Admiral Boulevard
Mississauga On L5T 2N6
CANADA
TEL: (905) 362 9707

U. S. A.

Roland Corporation U.S.
5100 S. Eastern Avenue
Los Angeles, CA 90040-2938,
U. S. A.
TEL: (323) 890 3700



As of November 1, 2006 (ROLAND)