

Roland®

MEMORY CARD
M-512G

RAM 64K BYTES

INSTRUCTIONS

Copyright © 2002 ROLAND CORPORATION
All rights reserved. No part of this publication may be reproduced in any form without the written permission of ROLAND CORPORATION.

Before using this card, make sure to read the instructions below.

■ NOTES

- Never touch terminals. Also, avoid getting terminals dirty.
- Do not expose the card to direct sunlight, place it near devices that radiate heat, leave it inside an enclosed vehicle, or otherwise subject it to temperature extremes. Excessive heat can deform or discolor the card.
- To avoid possible breakdown, do not use the card in a wet area, such as an area exposed to rain or other moisture.
- To avoid the risk of damage to internal components that can be caused by static electricity, please carefully observe the following whenever you handle the card.
 - Before you touch the card, always first grasp a metal object (such as a water pipe), so you are sure that any static electricity you might have been carrying has been discharged.
 - Save the bag and the box in which the card was originally shipped, and put the card back into them whenever you need to store or transport it.
- The face that you are holding the card with the bump up, and insert it slowly until it is securely in place.

Roland Corporation

Use only in the products which M-512E is designated.
This card can also be used which instruments with use M-256E, M-256D or M-128D.
(However, the amount of data that can be saved onto this card will be the same as when using a card originally specified for the instrument.)

- How to use the Memory Card is fully explained in the owner's manual of each device.

■ Battery Replacement

- When the display of your device using M-512G indicates a message such as "MEMORY CARD Battery Low" or "DATA Card Battery Low," the battery in M-512G card is nearly worn out. Please contact Roland Service Station for the battery replacement, referring to the owner's manual of your device.

▲WARNING Be sure to load all the data from the M-512G onto your device before the battery replacement. The data stored in your M-512G card may be lost while replacing the battery.

■ Protect Switch

The Protect Switch is provided to prevent accidental erasure of data. Please be sure to keep it in the ON position except when writing new data.

* In the interest of product improvement, the specifications and/or appearance of this card are subject to change without prior notice.

Roland

MEMORY CARD
M-512G

RAM 64K BYTES

取扱説明書

© 2002 ローランド株式会社
本書の一瓶、もしくは全部を無断で複写・転載することを禁じます。

このカードを使用する前に、以下の指示をよく読んでください。

ご注意

カードの端子の部分に触れたり、汚したりしないようにしてください。
直射日光の当たる場所や、発熱する機器の近く、閉め切った車内などに放置しないでください。変形、変色することがあります。故障の原因になりますので、雨や水に濡れる場所で使用しないでください。
このカードは、静電気がより部品が破壊される恐れがあります。カードを取り扱うときは、次の点に注意してください。
カードを持つときは、あらかじめ何らかの金属に触れて、体や衣類にたまっていく静電気を放電してください。
カードを保管するとき、または輸送するときなどは、購入時にカードが入っていた袋（導電袋）および外箱に入れてください。

カードは差し込み方向を確認の上、確実に奥まで差し込んでください。
メモリー・カードにデータを記憶させる方法や使用方法は、各機器の取扱説明書をお読みください。
お客様がこの機器を分解、改造された場合、以後の性能について保証できなくなります。また、修理をお断りする場合もあります。

ローランド株式会社

このカードは、使用可能なメモリー・カードとして、M-512Eが指定された機種のみにご使用ください。

なお、ローランド M-256E/M-256D/M-128Dが指定されている機種にも使うことができます。(ただしその場合、このカードに保存できるデータ量は、各機種で指定されているカードを使用したときと同じになります。)

電池交換

使用機器側で「MEMORY CARD Battery Low」,「DATA Card Battery Low」などのメッセージが表示されたら、メモリー・カードの電池が消耗しています。お買い上げ店またはローランド・サービスに電池交換を依頼してください。

▲警告 電池交換の際には、メモリー・カード内のデータが失われることがありますので、あらかじめデータを各使用機器等に記憶させてください。

フロッピー・ディスク

フロッピー・ディスクは、メモリー・カードに保存されているデータを誤って消去しないように保護するためのものです。新しくデータを記憶させるとき以外は、オフにしておいてください。

製品の仕様および外観は、改良のため予告なく変更することがあります。

Roland ローランド製品保証書 [持込修理]

お客様	ご芳名	様
	ご住所	〒 ----- ☎

取扱販売店名・住所・☎

保証期間	お買い上げ日	本体は一年間 <small>ただし、ソフトウェア、 付属品、消耗部品は除く</small>
	年 月 日より	

太枠内に記入のない場合は、必ず販売店発行の領収書またはそのお買い上げ年月日・販売店等を証明するものを保証書に添付願います。記入もしくは添付の無い場合は無効となりますのでご注意ください。

型名 **M-512G**

本保証書は、本書記載内容で無料修理をさせていただきますことをお約束するものです。

保証期間中に故障が発生した場合は、製品と本書をご持参ご提示の上、お買上げの販売店にご依頼ください。

ご転居・ご贈答品などの場合で、お買上げ販売店に修理を依頼することができない場合は、ローランドサービスステーションにお問い合わせください。

本書は再発行いたしません。所定事項を記入し、内容をよくお読みの上、大切に保存してください。



ローランド株式会社

本社 〒530-0004 大阪市北区堂島浜1-4-16 大和堂島ビル7F
電話 (06) 6345-9800

ローランドサービスステーションについては、各機器に付属の「サービスの窓口」をご覧ください。

保証規定

- 保証期間内において、取扱説明書・本体貼付ラベルなどの注意書に従った正常なご使用状態で発生した故障については、第3項に示す場合を除き、無料修理いたします。
- 保証期間内に無料修理をお受けになる場合は、お買上げの販売店、又は最寄りのローランドサービスステーションにご依頼のうえ、修理の際に本書をご提示ください。お客様のご事情により出張修理を依頼された場合、保証期間中であっても出張料金を申し受けます。
- 保証期間内でも、次の場合には有料修理となります。
 - 本書のご提示が無い場合。
 - 本書にお買い上げ年月日・販売店名の記入もしくは証明できるものの添付が無い場合、またはその字句を書き換えられた場合。
 - ご使用上の誤り、又は当社の指定者以外の手により修理・改造された場合。
 - 本製品に異常がなく、他の部分、他の機器に異常があり、点検及び改善した場合。
 - お買い上げ後の輸送、移動、落下等による故障や損傷および使用中に生じたキズ・汚れなどの外観上の変化。
 - 地震、落雷、風水害、その他の天災地変、火災、公害、ガス、異常電圧による故障や損傷。
 - 消耗部品（例：電池など）の取り替えを要する場合、および消耗部品の摩耗や劣化に起因する故障や損傷。
- 本製品は日本国内でご使用いただくことを前提に製造・販売しております。従って本製品の保証は、日本国外ではお受けできませんので、ご了承ください。
This warranty is valid only in Japan.

修理メモ

本保証書は以上の保証規定により無料修理をお約束するものです。従ってこの保証書によってお客様の法律上の権利を制限するものではありません。

本製品の補修用性能部品（製品の機能を維持するために必要な部品）の最低保有期間は製造打切後6年です。この部品保有期間を修理可能の期間とさせていただきます。保有期間経過後も、故障内容によっては修理可能の場合がありますので、ローランドサービスステーションまでお問い合わせください。

修理の際、交換した部品を再生、再利用、製品の品質向上等の目的で回収させていただくことがありますので、ご協力願います。



This product complies with the requirements of European Directive 89/336/EEC.

For EU Countries