SUPER PHASE SHIFTER SP400

Ultimate Phase Shifter Effects Pedal

Thank you for showing your confidence in us by purchasing the BEHRINGER SUPER PHASE SHIFTER SP400. This Phaser effects pedal delivers the whole history from vintage to modern phase shifting effects—at the touch of a foot switch. Experience sounds from classic multi-stage phasers to new swirling up- and downward moving sounds.

1. Controls



Select the effect mode via the **MODE** switch:

4/8/10/12-stage: This determines the number of stages for the phaser effect. The sound varies from vintage phaser sounds to deep and powerful phasing effects.

FALL: This mode gives you the impression of a constantly falling phasing sound.

RISE: This mode sounds like a permanently rising phasing sound.

STEP: In this mode, the filter modification occurs up and down in defined steps.

- **RES**(onance) controls the intensity of the effect.
- 3 With **DEPTH** you can set the modulation depth.
- 4 RATE determines the modulation speed. RATE can also be entered using the tap function of the foot switch or via an external expression pedal.
- Use the ¼" TS **IN** connector to plug in the instrument cable.
- 6 The ¼" TS **OUT** connector sends the signal to your amp or other effects devices.
- The ¼" TRS **EXP/CTL** connector can be used to connect two different types of pedals:
 - Use a foot switch instead of the pedals' foot switch (8) to tap the effect RATE.
 - Use an expression pedal to modulate the rate from 0 (modulation is stopped) to the maximum value which is determined by the position of the RATE knob 4.



- Use the foot switch to activate/deactivate the effect. When pressing the foot switch 2 seconds or longer, you can tap in the effect rate (ON/BATT LED flashes).
- The ON/BATT LED illuminates when the effect is activated. It also serves as a battery level indicator. If the Tap function is active, the LED flashes.

Use the **DC IN** connection to plug in a 9 V power supply (not included).

The **BATTERY COMPARTMENT** is located underneath the pedal cover. To install or replace the 9 V battery (not included), press the hinges with a ballpoint pen and remove the pedal cover. Be careful not to scratch the unit.

The SP400 has no On/Off switch. It is operable as soon as you insert a plug into the IN connector. Disconnect the plug, if you don't use the SP400. In doing so, you can extend the life time of the battery.

The **SERIAL NUMBER** is located at the underside.

In rare cases interferences of the normal function may appear by external influence (e.g. electrostatic discharge), as for example sound disturbances or malfunctions. If this occurs, please turn down the volume on subsequent amplifiers and disconnect the input connector briefly to restart the application.

2. Safety Instructions

Do not use near water, or install near heat sources. Use only authorized attachments/accessories. Do not service product yourself. Contact our qualified servicing personnel for servicing or repairs, especially when power supply cord or plug is damaged.

3. Warranty

Please register your new BEHRINGER equipment right after your purchase by visiting http://behringer.com and read the terms and conditions of our warranty carefully.

4. Specifications

ln .	
Connector	1/4" TS; 500 k0hm
0ut	
Connector	1/4" TS; 1 k0hm
EVD (CT)	
EXP/CTL	
Connector	1/4" TRS; 500 k0hm
Power Supply	
	9 V⋯, 100 mA regulated
BEHRINGER PSU-SI	В
USA/Canada	120 V~, 60 Hz
China/Korea	220 V~, 50/60 Hz
Europe/Australia	230 V~, 50 Hz

100 V~, 50 - 60 Hz

Power connector	2 mm DC jack, negative center
Battery	9 V type 6LR61
Power consumption	60 mA

Physical/Weight	
Dimensions (H x W x D)	approx. 2 1/8 x 2 3/4 x 4 4/5" approx. 54 x 70 x 123 mm
Weight	approx. 0.73 lbs / 0.33 kg

BEHRINGER is constantly striving to maintain the highest professional standards. As a result of these efforts, modifications may be made from time to time to existing products without prior notice. Specifications and appearance may therefore differ from those listed or shown.

TECHNICAL SPECIFICATIONS AND APPEARANCES ARE SUBJECT TO CHANGE WITHOUT NOTICE AND ACCURACY IS NOT GUARANTEED. BEHRINGER IS PART OF THE MUSIC GROUP (MUSIC-GROUP.COM.). ALL TRADEMARKS ARE THE PROPERTY OF THEIR RESPECTIVE OWNERS. MUSIC GROUP ACCEPTS NO LIABILITY FOR ANY LOSS WHICH MAY BE SUFFERED BY ANY PERSON WHO RELIES EITHER WHOLLY OR IN PART UPON ANY DESCRIPTION, PHOTOGRAPH OR STATEMENT CONTAINED HERRIC. COLORS AND SPECIFICATIONS MAY VARY FROM ACTUAL PRODUCT. MUSIC GROUP PRODUCTS ARE SOLD THROUGH AUTHORIZED FULLFILLERS AND RESELLERS ONLY. FULLFILLERS AND RESELLERS ARE NOT AGENTS OF MUSIC GROUP PAND HAVE ABSOLUTELY NO AUTHORITY TO BIND MUSIC GROUP BY ANY EXPRESS OR IMPLIED UNDERTRAING OR REPRESENTATION. THIS MANUAL IS COPYRIGHTED. NO PART OF THIS MANUAL MAY BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC OR MECHANICAL, INCLUDING PHOTOCOPYING AND RECORDING OF ANY KIND, FOR ANY PURPOSE, WITHOUT THE EXPRESS WRITTED IN AUTHORISE CROUP IP LTD. ALL RIGHTS RESERVED. © 2012 MUSIC Group IP Ltd. Trident Chambers, Wickhams Cay, P.O. Box 146, Road Town, Tortola, British Wirgin Islands



Japan