

SAMPLE SETTINGS

To help you get started using your **MXR DD-11 Dime Distortion**, we've provided a roadmap of knob and switch settings. Please note that these tones were dialed in through a clean, moderately loud amplifier.



DIME SOUND



ROCK DISTORTION



Use these diagrams to document your favorite settings.



DD-11 Dime Distortion

FAR BEYOND DISTORTION

When Dimebag Darrell of Pantera first exploded on the scene, he ushered in a new era of tone and attitude. When it comes to guitar, Dime doesn't need a "warm" or "pretty" sound. He can't be bothered with "vintage" this or "boutique" that. He wants a heavy, aggressive, razor-sharp tone that can slice through a loud band and a louder crowd. It's a tone that rages with distortion but remains tight and focused enough to keep up with lightening-fast rhythm lines and face-melting solos.

Finally there's a pedal that can deliver all that:
the Dime Distortion from MXR.

DIME[®]

DISTORTION



LIVE TO PLAY LIVE[®]

DUNLOP MANUFACTURING, INC. P.O. BOX 846 BENICIA, CA 94510 U.S.A.
TEL: 1-707-745-2722 FAX: 1-707-745-2658 WWW.JIMDUNLOP.COM

92503002484



CONTROLS

- 1 3-band EQ for huge lows and paint-peeling highs
- 2 Proprietary Scoop switch notches mids for modern metal death tones
- 3 Gain
- 4 Output
- 5 Indestructible die-cast zinc housing

Congratulations on your purchase of your new MXR Dime Distortion! MXR is a pioneer of distortion box technology and MXR effects are chosen by guitarists the world over for their bullet-proof construction and spectacular tone. Please take a minute to read through this manual so you can get the most out of your Dime Distortion.

DESCRIPTION

- Thick, powerful distortion with amazing definition
- Proprietary Scoop switch notches mids for deadly modern metal tones
- 3-band EQ provides huge tonal flexibility

POWER

The MXR Dime Distortion requires an ECB-04 18-volt power supply (included). The MXR Dime Distortion can also be powered by the DCB-10 (Dunlop DC Brick).

CONTROLS

Effect footswitch toggles effect on/hardwire bypass (red LED Indicates on). Mid Scoop switch (engage switch for the Dimebag sound). Output knob adjusts the overall output level. Bass/Mid/Treb EQ knobs allow tonal fine-tuning. Gain knob adjusts the amount of distortion.

DIRECTIONS

To begin using your MXR Dime Distortion, run a cable from your guitar to the Dime's input jack and run another cable from the Dime's output jack to your amplifier. For starters, set all of the controls to their 12 o'clock position and turn the effect on by hitting the footswitch (red LED on). Now dial in as much distortion as you want with the Gain knob. Once you've set the amount of distortion to your liking, you can modify the tone radically with the 3-band EQ and the Scoop switch. Check out the sample settings in this manual for some of the many great sounds the Dime is capable of.

NOTE

Because of the Dime Distortion's huge levels of gain and EQ, extreme settings (i.e. everything up all the way) will create feedback. To avoid this, back off Gain or EQ knobs slightly.