

EN SERIES SOUND AND RHYTHM GUIDE

SOUND VARIATIONS

EN1

SOUND SELECT		SOUND NAME	MIDI PROGRAM CHANGE DATA	
			NORMAL	TECHNICS
UPPER	PIANO	PIANO	5	0
	E PIANO	ELECTRIC PIANO	6	5
	HARPSICHORD	HARPSICHORD	7	16
	GUITAR	CLASSICAL GUITAR	8	20
	JAZZ GUITAR	JAZZ GUITAR	9	25
	BRASS	BRASS	0	56
	SAX	TENOR SAX	1	78
	CLARINET	CLARINET	2	68
	FLUTE	FLUTE	3	65
	STRINGS	STRINGS	4	100
LOWER	PIANO	PIANO	4	0
	E PIANO	ELECTRIC PIANO	5	5
	HARPSICHORD	HARPSICHORD	6	16
	GUITAR	CLASSICAL GUITAR	7	20
	BRASS	BRASS	0	56
	SAX	TENOR SAX	1	78
	ACCORDION	ACCORDION	2	80
	STRINGS	STRINGS	3	100
BASS	ORGAN	16' + 8'	0	95
	ACOUSTIC	ACOUSTIC BASS	1	43
	ELECTRIC	ELECTRIC BASS	2	40
	TUBA	TUBA	3	55

EN2

SOUND SELECT		VARIATION		MIDI PROGRAM CHANGE DATA	
				NORMAL	TECHNICS
UPPER	PIANO	1 2	PIANO HONKY-TONK	5	0 1
	E PIANO	1 2	ELECTRIC PIANO 1 ELECTRIC PIANO 2	6	5 5
	HARPSICHORD	1 2	HARPSICHORD CEMBALO	7	16 18
	GUITAR	1 2	CLASSICAL GUITAR HAWAIIAN GUITAR	8	20 31
	ELECTR GUITAR	1 2	JAZZ GUITAR SOLID GUITAR	9	25 26
	BRASS	1 2	BRASS TRUMPET	0	56 48
	SAX/S BRASS	1 2	TENOR SAX SYNTH BRASS	1	78 60
	REED	1 2	CLARINET ACCORDION	2	68 80
	FLUTE	1 2	FLUTE PAN FLUTE	3	65 72
	STRINGS	1 2	STRINGS VIOLIN	4	100 96
LOWER	PIANO	1 2	PIANO HONKY-TONK	4	0 1
	E PIANO	1 2	ELECTRIC PIANO 1 ELECTRIC PIANO 2	5	5 5
	HARPSICHORD	1 2	HARPSICHORD CEMBALO	6	16 18
	GUITAR	1 2	CLASSICAL GUITAR JAZZ GUITAR	7	20 25
	BRASS	1 2	BRASS TRUMPET	0	56 48
	SAX/S BRASS	1 2	TENOR SAX SYNTH BRASS	1	78 60
	REED	1 2	CLARINET ACCORDION	2	68 80
	STRINGS	1 2	STRINGS VIOLIN	3	100 96
BASS	ORGAN	1 2	8' 16' + 8'	0	94 95
	ACOUSTIC	1 2	ACOUSTIC BASS STRINGS	1	43 102
	ELECTRIC	1 2	ELECTRIC BASS CHOPPER BASS	2	40 41
	SPECIAL	1 2	TUBA PIPE ORGAN	3	55 85

EN3

SOUND SELECT		VARIATION		MIDI PROGRAM CHANGE DATA	
				NORMAL	TECHNICS
UPPER	PIANO	1 2	PIANO HONKY-TONK	5	0 1
	E PIANO	1 2	ELECTRIC PIANO 1 ELECTRIC PIANO 2	6	5 6
	HARPSI/VIBES	1 2	HARPSICHORD VIBRAPHONE	7	16 8
	GIUITAR	1 2	CLASSICAL GUITAR HAWAIIAN GUITAR	8	20 31
	ELECTR GUITAR	1 2	JAZZ GUITAR SOLID GUITAR	9	25 26
	BRASS	1 2	BRASS TRUMPET	0	56 48
	SAX/S BRASS	1 2	TENOR SAX SYNTH BRASS	1	78 60
	REED	1 2	CLARINET ACCORDION	2	68 80
	FLUTE	1 2	FLUTE PAN FLUTE	3	65 72
	STRINGS	1 2	STRINGS VIOLIN	4	100 96
LOWER	PIANO	1 2	PIANO HONKY-TONK	4	0 1
	E PIANO	1 2	ELECTRIC PIANO 1 ELECTRIC PIANO 2	5	5 6
	HARPSICHORD	1 2	HARPSICHORD CEMBALO	6	16 18
	GIUITAR	1 2	CLASSICAL GUITAR JAZZ GUITAR	7	20 25
	BRASS	1 2	BRASS TRUMPET	0	56 48
	SAX/S BRASS	1 2	TENOR SAX SYNTH BRASS	1	78 60
	REED	1 2	CLARINET ACCORDION	2	68 80
	STRINGS	1 2	STRINGS VIOLIN	3	100 96
BASS	ORGAN	1 2	8' 16' + 8'	0	94 95
	ACOUSTIC	1 2	ACOUSTIC BASS STRINGS	1	43 102
	ELECTRIC	1 2	ELECTRIC BASS CHOPPER BASS	2	40 41
	SPECIAL	1 2	TUBA PIPE ORGAN	3	55 85

EN4

SOUND SELECT		VARIATION		MIDI PROGRAM CHANGE DATA	
				NORMAL	TECHNICS
UPPER	PIANO	1	PIANO	7	0
		2	BRIGHT PIANO		1
		3	HONKY-TONK		1
	E PIANO	1	ELECTRIC PIANO 1	8	5
		2	ELECTRIC PIANO 2		6
		3	ELECTRIC PIANO 3		5
	HARPSICHORD	1	HARPSICHORD	9	16
		2	CEMBALO		18
		3	HARP		32
	MALLET	1	VIBRAPHONE	10	8
		2	GLOCKENSPIEL		9
		3	STEEL DRUM		15
	GUITAR	1	CLASSICAL GUITAR	11	20
		2	12-STRING GUITAR		23
		3	HAWAIIAN GUITAR		31
	ELECTR GUITAR	1	JAZZ GUITAR	12	25
2		SOLID GUITAR	26		
3		MUTE GUITAR	29		
SYNTH	1	SYNTH CLAVI	13	115	
	2	SYNTH GRAND		114	
	3	AFRICAN		113	
BRASS	1	BRASS	0	56	
	2	TROMBONE		53	
	3	FRENCH HORN		54	
TRUMPET	1	TRUMPET	1	48	
	2	MUTE TRUMPET		50	
	3	FLÜGELHORN		51	
SAX/S BRASS	1	TENOR SAX	2	78	
	2	ALTO SAX		77	
	3	SYNTH BRASS		60	
REED	1	CLARINET	3	68	
	2	BRIGHT ACCORDION		80	
	3	MUSETTE ACCORDION		82	
FLUTE/OBOE	1	FLUTE	4	65	
	2	PAN FLUTE		72	
	3	OBOE		66	
VOCAL	1	VOCAL	5	104	
	2	SYNTH VOCAL		107	
	3	MELLOW ENSEMBLE		107	
STRINGS	1	STRINGS 1	6	100	
	2	STRINGS 2		102	
	3	VIOLIN		96	

SOUND SELECT		VARIATION		MIDI PROGRAM CHANGE DATA	
				NORMAL	TECHNICS
LOWER	PIANO	1	PIANO	5	0
		2	BRIGHT PIANO		1
		3	HONKY-TONK		1
	E PIANO	1	ELECTRIC PIANO 1	6	5
		2	ELECTRIC PIANO 2		6
		3	ELECTRIC PIANO 3		5
	HARPSICHORD	1	HARPSICHORD	7	16
		2	CEMBALO		18
		3	HARP		32
	GUITAR	1	CLASSICAL GUITAR	8	20
2		12-STRING GUITAR	23		
3		HAWAIIAN GUITAR	31		
ELECTR GUITAR	1	JAZZ GUITAR	9	25	
	2	SOLID GUITAR		26	
	3	MUTE GUITAR		29	
BRASS	1	BRASS	0	56	
	2	TROMBONE		53	
	3	FRENCH HORN		54	
SAX/S BRASS	1	TENOR SAX	1	78	
	2	ALTO SAX		77	
	3	SYNTH BRASS		60	
REED	1	CLARINET	2	68	
	2	BRIGHT ACCORDION		80	
	3	MUSETTE ACCORDION		82	
VOCAL	1	VOCAL	3	104	
	2	SYNTH VOCAL		107	
	3	MELLOW ENSEMBLE		107	
STRINGS	1	STRINGS 1	4	100	
	2	STRINGS 2		102	
	3	VIOLIN		96	
BASS	ORGAN	1	8'	0	94
		2	16'		94
		3	16' + 8'		95
	ACOUSTIC	1	ACOUSTIC BASS 1	1	43
		2	ACOUSTIC BASS 2		43
3		STRINGS	102		
ELECTRIC	1	ELECTRIC BASS 1	2	40	
	2	ELECTRIC BASS 2		40	
	3	MUTE BASS		47	
CHOPPER	1	CHOPPER BASS 1	3	41	
	2	CHOPPER BASS 2		41	
	3	SYNTH CHOPPER BASS		45	
SPECIAL	1	TUBA	4	55	
	2	PIPE ORGAN 1		85	
	3	PIPE ORGAN 2		84	

RHYTHM VARIATIONS/ONE TOUCH PLAY

EN1/EN2

RHYTHM		VARIATION	ONE TOUCH PLAY
MARCH	1	U.S.A. MARCH 2/4	MARCHING BAND
	2	POLKA	ACCORDION BAND
COUNTRY	1	COUNTRY	COUNTRY & WESTERN GUITARS
	2	BLUEGRASS	COUNTRY ORCHESTRA
WALTZ	1	CHANSON WALTZ	STANDARD ORGAN WALTZ
	2	JAZZ WALTZ	JAZZ WALTZ COMBO
SWING 1	1	BIG BAND 1	REED SECTION
	2	BIG BAND 2	WOOD & BRASS
SWING 2	1	JAZZ COMBO	TENOR LEAD
	2	DIXIE	BOO BOOP BE DOO
8 BEAT	1	8 BEAT BALLAD	GENTLE EIGHT
	2	8 BEAT ROCK	REED LEAD
ROCK	1	ROCK BALLAD	TENOR BALLAD
	2	SHUFFLE BOOGIE	BOOGIE PIANO
16 BEAT 1	1	16 BEAT ROCK	STANDARD 16
	2	16 BEAT BALLAD	BALLAD 16
16 BEAT 2	1	SAMBA ROCK	SHAKA PIANO
	2	JAZZ ROCK	JAZZ GUITAR LEAD
DISCO	1	DISCO	VOGUE FLUTE LEAD
	2	DISCO EURO BEAT	DISCO ORCHESTRA
LATIN 1	1	RHUMBA	PIANO & STRINGS
	2	TANGO	TANGO ACCORDION
LATIN 2	1	BOSSA NOVA	LIGHT BOSSA
	2	SAMBA	MODERN SAMBA

EN3

RHYTHM		VARIATION	ONE TOUCH PLAY
MARCH	1	U.S.A. MARCH 2/4	MARCHING BAND
	2	GERMAN MARCH 6/8	MILITARY BAND
	3	POLKA	ACCORDION BAND
COUNTRY	1	COUNTRY	COUNTRY & WESTERN GUITARS
	2	BLUEGRASS	COUNTRY ORCHESTRA
	3	FOXTROT	DANCE COMBO
WALTZ	1	CHANSON WALTZ	STANDARD ORGAN WALTZ
	2	VIENNESE WALTZ	VIENNESE ORCHESTRA
	3	JAZZ WALTZ	JAZZ WALTZ COMBO
SWING 1	1	BIG BAND 1	REED SECTION
	2	BIG BAND 2	WOOD & BRASS
	3	BIG BAND 3	WARM REEDS
SWING 2	1	JAZZ COMBO	TENOR LEAD
	2	JAZZ BALLAD	SHEER JAZZ
	3	DIXIE	BOO BOOP BE DOO
8 BEAT	1	8 BEAT BALLAD	GENTLE EIGHT
	2	8 BEAT ROCK	ROCK ORCHESTRA
	3	8 BEAT SOUL	REED LEAD
ROCK	1	ROCK BALLAD	TENOR BALLAD
	2	SHUFFLE BOOGIE	BOOGIE PIANO
	3	ROCK 'N' ROLL	SIXTIES POP REED
16 BEAT 1	1	16 BEAT ROCK 1	STANDARD 16
	2	16 BEAT BALLAD	BALLAD 16
	3	16 BEAT ROCK 2	TRUMPET 16
16 BEAT 2	1	SAMBA ROCK	SHAKA PIANO
	2	JAZZ ROCK	JAZZ GUITAR LEAD
	3	SOUL ROCK	SOUL SYNTH E.P.
DISCO	1	DISCO	VOGUE FLUTE LEAD
	2	DISCO EURO BEAT	DISCO ORCHESTRA
	3	16 BEAT DISCO	DISCO FRETS
LATIN 1	1	RHUMBA	PIANO & STRINGS
	2	MAMBO	LATIN BRASS
	3	TANGO	TANGO ACCORDION
LATIN 2	1	BOSSA NOVA 1	LIGHT BOSSA
	2	BOSSA NOVA 2	FLUTE & FRET
	3	SAMBA	MODERN SAMBA

EN4

RHYTHM	VARIATION		ONE TOUCH PLAY
MARCH	1	U.S.A. MARCH 2/4	MARCHING BAND MILITARY BAND ACCORDION BAND
	2	GERMAN MARCH 6/8	
	3	POLKA	
COUNTRY	1	COUNTRY	COUNTRY & WESTERN GUITARS COUNTRY ORCHESTRA DANCE COMBO
	2	BLUEGRASS	
	3	FOXTROT	
WALTZ 1	1	VIENNESE WALTZ	VIENNESE ORCHESTRA STANDARD ORGAN WALTZ FLÜGEL WALTZ
	2	CHANSON WALTZ	
	3	GERMAN WALTZ	
WALTZ 2	1	JAZZ WALTZ 1	JAZZ WALTZ COMBO MALLET JAZZ ROMANTIC WALTZ
	2	JAZZ WALTZ 2	
	3	STANDARD WALTZ	
SWING 1	1	BIG BAND 1	REED SECTION WOOD & BRASS WARM REEDS
	2	BIG BAND 2	
	3	BIG BAND 3	
SWING 2	1	JAZZ COMBO	TENOR LEAD SHEER JAZZ BOO BOOP BE DOO
	2	JAZZ BALLAD	
	3	DIXIE	
8 BEAT	1	8 BEAT BALLAD	GENTLE EIGHT ROCK ORCHESTRA REED LEAD
	2	8 BEAT ROCK	
	3	8 BEAT SOUL	
ROCK	1	ROCK BALLAD	TENOR BALLAD BOOGIE PIANO SIXTIES POP REED
	2	SHUFFLE BOOGIE	
	3	ROCK 'N' ROLL	
16 BEAT 1	1	16 BEAT ROCK 1	STANDARD 16 BALLAD 16 FLÜGEL 16
	2	16 BEAT BALLAD	
	3	16 BEAT ROCK 2	
16 BEAT 2	1	SAMBA ROCK	SHAKA PIANO POP SYNTH PIANO CHORUS
	2	POP ROCK	
	3	SWING ROCK	
JAZZ ROCK	1	JAZZ ROCK 1	JAZZ GUITAR LEAD MUTE GUITAR LEAD SOUL SYNTH E.P.
	2	JAZZ ROCK 2	
	3	SOUL ROCK	
DISCO	1	DISCO	VOGUE FLUTE LEAD DISCO ORCHESTRA DISCO FRETS
	2	DISCO EURO BEAT	
	3	16 BEAT DISCO	
LATIN 1	1	RHUMBA	PIANO & STRINGS LATIN BRASS TANGO ACCORDION
	2	MAMBO	
	3	TANGO	
LATIN 2	1	BOSSA NOVA 1	LIGHT BOSSA FLUTE & FRET MODERN SAMBA
	2	BOSSA NOVA 2	
	3	SAMBA	

COMPOSER (EN3/EN4)

The **COMPOSER 1~8** buttons are for storing your original rhythm patterns. However, the following rhythm patterns are preset in the buttons at the time of shipment from the factory.

No.	RHYTHM	No.	RHYTHM
1	WALTZ	5	BOSSA NOVA
2	FOXTROT	6	RHUMBA
3	JAZZ FAST	7	8 BEAT
4	CHA-CHA	8	16 BEAT

KEYBOARD PERCUSSION (EN2/EN3/EN4)

