



DMC-6 Gen3 DMC-8 Gen3



User Manual v1.05e

Revision History:

v1.05 - way too many changes to list here. Let's just say there's a lot.

v1.02c

- * added Hologram Dream Sequence device
- * added Memory Protect option in Setup
- * added 6-channel configuration for Expression input jack
- *
- * v1.02b
- * added MIDI notes / ACCESS mode
- * fixed issue with expression not sending to E and F devices

v1.02a

- * Added MultiJack Toggle device
- * Added TOGG option to MultiJack setup
- * Fixed minor errors with preset name editing

v1.01d

- * Corrected a typo in the Eventide config section
- * Fixed an issue with the expression input + latching freeze setup

v1.01c

- * Fixed an issue with adjusting BPM in 0.5 increments
- * Fixed an issue with selecting USB HOST or MIDI if clock is enabled
- * Fixed an issue with naming banks and preset zero

v1.01b

- * Added bank names + config

v1.01a

- * Fixed an issue with loading names after FAVE is called
- * Fixed DD500 tap
- * Added Atomic AmpliFIRE device

v1.01 - 10/21/16

- * Added USB Mode configuration - user may now select USB MIDI or HOST in setup menu.

v1.00

- * Initial Release

1. Introduction

Thanks for purchasing a Disaster Area Designs DMC-6 / DMC-8 Gen3 controller. We've worked hard for the last two years developing and refining our MIDI controller technology, and we've incorporated suggestions from players all over the world. The Gen3 controllers have more features, more functions, and more connectivity than any of our previous controllers. In this manual we'll cover the operating modes, setup, and use of the Gen3 controllers. Have fun!

The DMC-6 and DMC-8 Gen3 are compact MIDI controllers designed to interface with a wide variety of musical equipment. Up to six MIDI devices may be controlled by the Scrolling and Preset modes, for program selection and recall. The Preset mode may also control a seventh MIDI device with the capability for MIDI learning, such as the Disaster Area DPC-8EZ or SMARTSwitch.


If your MIDI device is equipped with a phrase looper / loop recorder mode, the DMC Gen3 may be able to control it. Looper modes for the Strymon Timeline, Line 6 M9 / M13, and Eventide H9 are supported at this time. Boss DD-500 and Pigtronix Infinity looper support is planned for a future update. Note: Using the looper disables one of the available MIDI devices in scrolling and preset modes.

The DMC Gen3 controllers can also serve as a pedalboard clock source. The Tap and Clock modes serve to select preset beats-per-minute (BPM) tempo and the DMC will send these clock signals out using a combination of MIDI and tap tempo output to a variety of compatible devices.

2. Controls and Connections

CONTROL PANEL

The DMC-6 Gen3 and DMC-8 Gen3 have the same basic controls: Buttons A, B, C, and D are located on the left side of the device, and the SAVE / UP and TAP / DOWN buttons are on the right side. The DMC-8 Gen3 has additional TAP and FAVE buttons at the far right side of the control panel. Please note that throughout this manual we will refer to the TAP / DOWN and the DOWN buttons interchangeably.



REAR PANEL



MIDI Output: Standard 5-pin MIDI output, connects to your first MIDI pedal input.

MIDI Input: The MIDI output jack doubles as a MIDI input using a Disaster Area MIDI Y-cable (sold separately.) The MIDI input allows the DMC Gen3 to accept incoming MIDI messages and merge them in with its own data stream.

Expression Input: The black jack is a multi-function connector that can accept an expression pedal or a momentary footswitch. Consult the Expression section for more details.

DC 9V: Standard DC power supply input, 9V center negative. The DMC Gen3 requires approximately 80mA if used by itself. If an external USB HOST device is connected, the DMC will need to be supplied with enough current to power both itself and the USB device.

USB MIDI: The standard DMC firmware allows the USB port to function as a MIDI interface for your compatible PC, Mac, or iPad (using the Apple Camera Connection Kit.) The DMC will receive and send MIDI messages over USB for device control.

USB HOST: If the USB Host firmware is installed, the DMC USB port may be used to send and receive MIDI messages to supported USB devices.

Status Indicator: This is just a little LED that blinks to let you know the pedal is working. It also blinks at a slower rate to indicate that the pedal is in boot loader mode during a firmware update.

MultiJacks 1-3: The red, white, and blue connectors are our astounding MultiJacks! The MultiJacks can do all kinds of cool stuff, like receive expression or tap tempo, send taps to your devices, or even send MIDI to additional devices.

3. Getting Started with MIDI

MIDI might seem kind of intimidating or frustrating at first, but it's really not too complicated. MIDI stands for **Musical Instrument Digital Interface**, and it was created way back in the 1980's as a method for synthesizers to talk to each other. Today, we can use it for linking synths, effects units, computers, drum machines, samplers, pedals, and more.


MIDI units come in two basic types - controllers and devices. The DMC-6 / 8 Gen3 is a controller, so it sends out commands to the gear on your pedalboard. Your Timeline, BigSky, H9, etc. are devices, so they receive commands and change in response to them. With me so far? Good!

MIDI gear is linked by some kind of hardware connection, usually a five-pin cable with a big round plug on each end. Sometimes devices can accept MIDI over a USB connection or using a non-standard connector like a 1/4" plug. Generally you can link up multiple devices in a daisy-chain kind of like you'd do with regular pedals, by connecting the MIDI OUTPUT or THRU of the first device to the MIDI INPUT of the second device and so on. There are some devices that won't re-transmit MIDI, or that will mangle / interfere / drop messages, so sometimes you have to get creative with your routing.

Each MIDI device receives commands on one or more MIDI *channels*, and the standard MIDI specification allows for up to 16 channels to be transmitted on the same cable. Sometimes, devices can receive on *any* channel they see (that's called Omni) but usually they'll be set to listen to only a single channel.

The DMC series are designed to transmit commands to lots of devices - up to seven at the same time, and we send out commands to each device on its own MIDI channel. Again, the same cable can carry all of those commands so that makes it a bit more convenient for us when we're putting together a pedalboard or rack system.

One important thing to consider - the more MIDI devices you have chained end-to-end, the greater the chance that your MIDI communication will be slow or unreliable. We call this "MIDI lag," and it's a bummer. To get around this, you can use a controller with multiple MIDI outputs or a hardware MIDI Thru box to split your MIDI signal to two or more short chains.



Please note that the order that you plug your MIDI devices in does not have to be the same as the order you plug their audio cables!


4. Setting up the DMC Gen3

Now that we have an idea of what MIDI is for, and what it can do, let's get your rig set up!

The first thing you should do is connect your devices to the DMC Gen3 using MIDI cables. If you have a short MIDI chain (4 or fewer devices) then you should be able to daisy-chain your gear as shown in the first picture above (ALL DEVICES IN LINE.) If you are connecting a device that doesn't have a MIDI output then you may need to place it at the end of your MIDI chain. Some devices that have MIDI INPUT only include the Digitech Whammy, Source Audio Programmable EQ and Soundblox Pro, Alexander Super Radical and Oblivion, EHX 8-Step Program, Boss Slicer, etc. Other devices such as the Line 6 M5 / M9 / M13 have a MIDI OUTPUT jack but don't pass through incoming MIDI and so can't be used in the middle of a daisy-chain. You can either connect these at the end of your MIDI chain or use one of the DMC Gen3 MultiJack connectors as a second MIDI output for that device.

Once you have your cables connected, you should set up the DMC Gen3 using its setup menu. The setup menu is pretty comprehensive, and it has a lot of options. We'll focus on the basics in this section, but you can consult the Setup Menu section at the end of the manual for the full details.

To enter the setup menu, power the DMC Gen3 on and wait until you see "Gen3" on the display, then hold the A and B buttons. When the display scrolls "SETUP" release the buttons. Once you are in the setup menu, tap the A and B buttons to select from the available menus and tap the SAVE button to enter / exit the menus. Once you're inside a menu, you can tap the A and B button to change the menu options. When you're done, hold SAVE to save the setup and start using the controller.



Here's how to set up your devices: Enter setup as described above. The first menu you'll see is PRST, which allows you to select the number of available banks in Preset Mode. It's set to 12 by default, and we'll leave it alone.

Tap the B button until you see DEV. This tells the controller how many MIDI devices you want to connect. By default it's set to DevC, which tells the DMC that you have three devices hooked up. If you happen to have three, then you can skip the next part. Otherwise, tap the SAVE button to edit the DEV menu. Once inside, tap the A or B buttons until the correct number of devices is shown. If you have five devices, you should set this to DevE, if you have two then it should be DevB.

Once you have the correct number of devices set, tap SAVE to exit the DEV menu. Tap B until you see DevA. This is the Device Selection menu for the Device A. By default it's set to control a Strymon Timeline, but you should set this to match the device you've got connected. Tap SAVE to edit this menu, and you'll see the device name scroll on the display. Tap A or B to cycle through the available devices. Most are self-explanatory but there's a list of all the devices at the end of the manual. Once the DevA device matches what you have connected, tap SAVE to exit this menu. Repeat for all of the devices you have hooked up. You can leave any devices that you don't have connected alone, no need to change them.

There are a lot more setup options in the menu, but for now we will leave them set to defaults. Hold the SAVE button to store the configuration.

5. Setting up your MIDI Devices

Finally, you'll need to set up each of your devices in order to make sure that they operate correctly. Mainly you need to set them up to receive on the correct MIDI channels, but there are a few other parameters you may need to adjust to ensure full control.

STRYMON

Strymon devices need to be configured correctly in order to pass incoming data through to the next device in line. They also need to be set up in order to maintain bypass "trails" and to use the Timeline looper.

Strymon Timeline: Enter the Globals menu and configure as follows:

MIDITH ON	MIDIPA OFF
MIDICT OFF	MIDICH (Must match device selection - 1 for DevA, 2 for DevB, etc.)
MIDICL ON	MC SWP OFF
LPEXIT PLAY	BYPASS BUFBYP

Strymon Mobius and BigSky: Enter the Globals menu and configure as follows:

MIDITH ON	MIDIPA OFF
MIDICT OFF	MIDICH (Must match device selection - 1 for DevA, 2 for DevB, etc.)
BYPASS BUFBYP (recommended for BigSky, optional for Mobius)	
MIDICL ON Mobius,	OFF BigSky

EVENTIDE (H9, SPACE, TIMEFACTOR, MODFACTOR, PITCHFACTOR)

Eventide devices have a robust MIDI mapping capability, but none of their functions are set from the factory. In order for these devices to recognize the commands we send, a few parameters must be set in their MIDI menus.

If using H9 Control, navigate to Pedal -> MIDI Settings -> MIDI Channel
 Set MIDI Receive Channel match device selection - 1 for DevA, 2 for DevB, etc.
 Navigate to Pedal -> MIDI Settings -> Assign MIDI CC Messages.
 Map Tap Tempo to MIDI CC 44
 Map Performance Switch to MIDI CC 46
 Map Toggle Tuner to MIDI CC 69
 Map Activate to MIDI CC 42
 Map Set Expression Pedal Value to CC 48

If using the MIDI menu on the device itself:

Navigate to RCV CHANNEL and set to match device selection - 1 for DevA, 2 for DevB, etc.

Navigate to the RCV CTL menu and set the following

TAP	C44
HOTSW	C46
ACTIVE	C42
PEDAL	C48

If you plan to use the looper on the H9 or Timefactor, set the following:

Looper - Record	MIDI CC 87
Looper - Play	MIDI CC 86
Looper - Stop	MIDI CC 85
Looper - Empty	MIDI CC 90
Looper - Flip Direction	MIDI CC 94
Looper - Flip Octave	MIDI CC 95

LINE 6 (M5, M9, M13)

Line 6 devices must have their MIDI channel assignments set to match device selection - 1 for DevA, 2 for DevB, etc. Enter the pedal's PREFS menu, the MIDI settings are found on the second page. Additionally, ensure that the MNL SAVE / AUTOSAVE is set to MNL SAVE. This will prevent the DMC Gen3 from messing up the bypass states of your scenes.

CHASE BLISS AUDIO

Chase Bliss devices must be set to receive on the correct channel in order to operate with the DMC Gen3:

Set up the desired device Chase Bliss / CBA in the Setup Menu.

Save the settings and boot the DMC normally.

Hold the A button to enter Device Mode.

Tap the SAVE button until the device you've set up for CBA is displayed.

Make sure that the LED for the current device is lit. If it's off, hold the TAP / DOWN footswitch until it lights up.

Connect the Chase Bliss pedal or pedals to the MIDI chain using the Chase Bliss modified MIDIBox using a standard MIDI cable and TRS cable. Make sure that the MIDIBox is receiving power.

Power on the Chase Bliss pedal while holding its TAP and BYPASS footswitches down.

Tap the A or B footswitch on the DMC to send a program change message to the Chase Bliss pedal. The CBA pedal should now respond to program change, bypass, and tap messages correctly.

MULTIJACK / AMPLIFIER CONTROL

Set one of your devices as MultiJack in the Setup menu to allow the DMC Gen3 to control your amplifier channels or other remote switching. No device setup is needed, but note that the DMC Gen3 can only use the MultiJacks that have been configured as "TOGG" in Setup.

DISASTER AREA (DPC-8EZ, SMARTCLOCK, SMARTLOOP)


If you are connecting to a Disaster Area DPC-8EZ, SMARTClock, or SMARTLoop, the DMC Gen3 can automatically set them to the correct MIDI channel. Follow the instructions in the DPC or SMARTPedal manual concerning **AutoConfig**.

If you are connecting to one of the above Disaster Area devices please note that the DMC Gen3 sends a large number of MIDI messages especially when the Preset and Global Clock modes are active. We recommend you connect the DPC and SMARTPedals last in the MIDI chain, or that you use a TRS to MIDI cable from the MultiJack. If using the MultiJack, we recommend you set the Jack Channel to J000, which will filter out MIDI clock messages and prevent them being sent to DPC or SMARTPedals.

If you are connecting to a Disaster Area SMARTClock, set the SMARTClock CHAN to 16 in its setup menu and disable the Preset and Global Clock modes on the DMC Gen3. If the Tap Tempo mode is enabled, you can tap tempos to the SMARTClock from the DMC Gen3.

6. Device Mode

Device Mode allows you to change presets and bypass your connected devices. You can access Device Mode by holding down the A button from any mode except Looper or Clock.



Device Mode Controls:

- A: Decrease the preset for the current device by one
- B: Increase the preset for the current device by one
Hold to enter Preset Mode
- C: Decrease the preset for the current device by one bank (Strymon) or by ten (all other devices)
Hold to enter Looper Mode
- D: Increase the preset for the current device by one bank (Strymon) or by ten (all other devices)

If you have configured one of your devices as “MultiJack” in the setup, the functions for that device only are as follows:

- A: Activate or deactivate MultiJack 1 (red)
- B: Activate or deactivate MultiJack 2 (white)
- C: Activate or deactivate MultiJack 3 (red)
- D: No action

The remaining buttons are the same regardless of the configured device:


- TAP / DOWN: Tap to tap tempo to all devices, hold to bypass or engage the current device.
- SAVE / UP: Tap to select the next available device. Hold to save the current settings to a preset.

Device Mode Tips:

Device Mode for manually changing settings on your MIDI devices. Scroll around until you find a sound you like, then move to the next device and do the same. When you’ve got all of your devices set where you like, you can save all of those programs to a combined preset for instant access later. If you’re using one of your devices for amplifier / remote control with the MultiJacks, you can instantly access all three jack settings, and those settings will be recalled along with your presets. Please consult the Preset Mode section for details on saving presets.

7. Preset Mode

Preset Mode allows you to recall and save presets on the DMC Gen3. Accessing a preset in this mode can change the programs on any or all of your connected devices, as well as changing the tempo / BPM, and sending commands to a loop switcher such as the DPC-8EZ. You can access Preset Mode by holding down the B button from any mode except Looper or Clock.



Preset Mode Controls:

- A: Load the A preset for the current bank or bypass if A was previously selected.
Hold to enter Device Mode
- B: Load the B preset for the current bank or bypass if B was previously selected.
Hold to enter Preset Mode
- C: Load the C preset for the current bank or bypass if C was previously selected.
Hold to enter Looper Mode
- D: Load the D preset for the current bank or bypass if D was previously selected.

TAP / DOWN: Tap to tap tempo to all devices, hold to decrease bank.

(optionally if T FS is set to BANK in Setup)

Tap to decrease bank, hold to enter Clock Mode


SAVE / UP: Tap to increase bank. Hold to save the current settings to a preset.

8. Saving a Preset

1. Use Device Mode to select the programs and set the bypass state for each of your connected devices.
2. Hold the SAVE / UP button to begin the save process.
3. Tap the SAVE / UP or TAP / DOWN buttons to select the desired preset bank.
4. Tap the A, B, C, or D buttons to select the desired preset.
5. Hold the SAVE / UP button to save the preset to the selected location.

(Optional) If Preset Names are selected in the DMC Gen3 Setup

6. Tap the C or D buttons to move to the previous / next letter in the preset name. 8 letters are available for each preset.
7. Tap the A or B buttons to change the currently selected character in the preset name.



8. Hold the SAVE / UP button again to save the name and the preset.

Preset Mode Tips:

You may cancel a preset save at any time by holding the A, B, C, or D buttons.

The "bypass" / zero preset is a special case. If you press the button of the currently loaded preset while in Preset Mode, the DMC Gen3 will bypass by loading the zero preset. If you would like to use the zero preset as a "favorite" sound, you can overwrite the default values just like any other preset. Edit the preset like normal, but when you enter the preset save process, tap any of the preset select buttons twice to load and then unload the preset location. The preset bank number will be displayed, but no preset (example P00 if you are in bank 0.) If you save the preset with only the bank number showing, the DMC Gen3 will save the current programs and bypass state to the zero preset.

Bank Names:

If the "BNAM" option is set to something other than "OFF," then you can save a name to each bank. This is great for setting up the base bank as the song title and then having each preset serve as a song section such as Verse, Chorus, or Solo.

To save the bank name, enter the bank where you'd like to save and press the preset buttons until the A,B,C, and D LEDs are OFF. Then, save the preset as normal - you'll be prompted for the name of the bank. Edit the name and SAVE, and you're all done.

Memory Protect:

If the "PROT" option is set to "ON" in the DPC-5 Gen3 Setup, the preset memory protection is activated. While the memory protection is active, the DMC Gen3 will not allow the user to save changes to presets, preset names, or bank names. This function is useful for live performance, to prevent accidental preset editing.

To disable memory protection, set "PROT" to "OFF" in the DMC Setup.

9. Looper Mode

Looper Mode allows you to control the loop recorder / phrase looper on supported devices. At this time, the DMC Gen3 supports looper control of the Strymon Timeline, Eventide H9 and Timefactor, and Line 6 M9 / M13. Please note that in order to use the Eventide H9 or Timefactor looper you must first set up a preset on the Eventide pedal with the Looper algorithm selected. Once that preset is activated, the Looper Mode will be able to control the Eventide pedal.

Looper Mode Controls:

A: Record / Overdub / Play. Tapping this button will start the loop recording. Tap again to set the loop length and begin overdubbing. Tap again to stop overdubbing and enter playback. You may tap this button at any time while the loop is recording to overdub additional parts.


B: Play. Tapping this button will set the loop length and begin playback if the loop is recording. If the loop is overdubbing, this button will cancel overdubbing and begin playback. If the loop is playing, pressing this button will restart the loop playback from the beginning.

TAP / DOWN: Stop / Undo (Redo) Tapping this button will stop the loop playback. Hold this button to send the Undo / Redo command.

C: Reverse. Tap this button to reverse the loop playback direction.

D: Half Speed / Octave. Tap this button to toggle the loop playback speed between half speed and full speed.

SAVE / UP: Exit looper mode.




10. Tap and Clock Mode

The DMC Gen3 now supports a full-featured tap tempo and MIDI clock controller, integrated with the Preset and Device Modes.

Tap Mode Controls:

Enabling Tap and Clock Modes allows the DMC Gen3 to send MIDI clock signals to connected devices, as well as to optionally send taps using MIDI CC messages and / or analog taps from the MultiJacks.



In the Setup Menu, there are four options for Tap and Clock Mode, each with different levels of functionality so that the user can decide the type of tempo control.

Setup Menu Option	Description	How is the tempo set?	What kind of messages does the controller send?	Does the BPM change with each preset?
t OFF	Clock mode is disabled	Tap tempo inputs (EXP, MULTI, TAP / DOWN)	MIDI CC messages Tap out from MULTI*	No
t TAP	Clock mode is set to TAP TEMPO	Tap the controller in TAP mode. Tap tempo inputs (EXP, MULTI, TAP / DOWN)	MIDI CC messages Tap out from MULTI*	No
t CLK	Clock mode is set to PRESET MIDI CLOCK	Tap tempo inputs (EXP, MULTI, TAP / DOWN) Set BPM directly on the controller (scroll left and right to decrease / increase BPM)	MIDI Clock Tap out from MULTI*	Yes
t TC	Clock mode is set to GLOBAL MIDI CLOCK	Tap the controller in TAP mode. Tap tempo inputs (EXP, MULTI, TAP / DOWN)	MIDI Clock Tap out from MULTI*	No

11. Expression Input and Side Roller

The DMC Gen3 is equipped with a dedicated input jack that may be assigned to a variety of control functions. Depending on the configuration of the Expression Input, either an expression pedal using a 10k-100k potentiometer or a momentary normally-open footswitch may be connected. If an expression pedal is used, the connection should be made with a tip-ring-sleeve / TRS / stereo cable. Tip = 0-3.3V, Ring = 3.3V, Sleeve = GND.

The DMC Gen3 may also be equipped with a side roller potentiometer as a factory option. In previous versions of the DMC series, the side roller shared an input channel with the external expression input and the two could not be used simultaneously. The Gen3 improves upon this arrangement by assigning each input its own dedicated channel, and each may be assigned separately to any combination of destinations.

To review the Expression Input or Side Roller options please consult the EXP and ROLL options in the Setup Menu. Note that the E CH and R CH menu options determine which MIDI channels each input will use for sending messages.

Example: The user has connected a Strymon Timeline (B) and Mobius (A.) The user wishes to have the side roller control the looper volume level for the Timeline and for the expression input to control the expression parameters for both Timeline and Mobius.

The menu options should therefore be set to EXP = EXPR, E CH1 = AB0, ROLL = LPR, R CH = 0B0. This sets the expression input to expression and allows it to send to the A and B devices, and the roller to send looper level for the B device only.

12. FAVE Switch

The DMC-8 adds a configurable extra button that may be programmed to suit a variety of uses.

- fOFF - FAVE is disabled, this should be selected if using a DMC-6
- fTAP - FAVE functions as tap tempo footswitch
- fLATC - FAVE functions as latching freeze / hold footswitch
- fFAV - FAVE loads and saves the Favorite preset
- fTUN - FAVE activates the tuner on supported devices
- fBNK - FAVE functions as a Bank Down button

The Setup Menu FAVE and F CH options cover the assignment of the FAVE Switch. As with the Expression input and MultiJacks, the FAVE Switch will only send messages to the channel(s) configured in the F CH option.

13. MultiJacks

The DMC Gen3 controllers incorporate a flexible input / output connector called the MultiJack. The MultiJacks are found on the connection panel of the Gen3, and will be indicated by a red, white, or blue jack nut. The MultiJack may function in one of several different configurations, depending on what you need.

Run the DMC Setup to configure the MultiJacks - the relevant menu entries MJ1 / 1 CH, MJ2 / 2 CH, and MJ3 / 3CH.

Each MultiJack has a variety of possible configurations. Note that MultiJack 2 (white) may connect with a two-button Expander Switch (sold separately) to perform additional functions.

MultiJack 1 (RED)	MultiJack 2 (WHITE)	MultiJack 3 (BLUE)	Description
OFF	OFF	OFF	MultiJack is disabled
EXPR			Expression pedal input
TAP		TAP	Tap Tempo footswitch input
	2TAP		Expander Switch Input (Tap Tempo and Favorite)
	2LPR		Expander Switch Input (Looper Control)
N-O	N-O	N-O	Tap Tempo output (normally open)
N-C	N-C	N-C	Tap Tempo output (normally closed / Boss)
MIDI	MIDI	MIDI	MIDI output
TOGG	TOGG	TOGG	MultiJack functions as amplifier or remote foot switch contact
	2BNK		Expander Switch Input (Bank Up and Down)

J CH - MultiJack channel selection

A B C MultiJack enable / disable

If the location shows as zero, the controller will not transmit expression or MIDI on that channel


If all three locations show as zero and the MultiJack is set to EXPR, no expression will be sent

If all three locations show as zero and the MultiJack is set to MIDI, all channels will be active but MIDI clock will not be sent

These settings do not affect any MultiJacks set to TOGG.

In addition, each MultiJack has a group of DIP switches inside the controller used to configure the hardware operation of the jack. **MJ1 uses three DIP switches, MJ2 and MJ3 use four.** The far-right switch for MJ2 and MJ3 should always be opposite the other three - **ON-ON-ON-OFF** or **OFF-OFF-OFF-ON**.

To use an output for TOGG, set it the same as for Tap Tempo / Clock Output (**OFF-OFF-OFF** or **OFF-OFF-OFF-ON**.)



14. MultiJack Examples

That's a lot of acronyms and data, so let's break it down based on the most common uses of the MultiJack:

If you have a pedal made by Chase Bliss Audio or certain Empress pedals (Reverb, Tremolo 2) then you can use the MultiJack to send them MIDI commands without using the MIDIBox peripheral.

SET MJ1, MJ2, and / or MJ3 to MIDI

SET 1 CH, 2 CH, or 3CH to the channel you would like to assign to the device (A, B, C) or to 000.

Ex. if you want to use a Tonal Recall as your "C" device, you can set J CH to 00C.

If you set the channel assignment to 000, the MultiJack will send MIDI data on all channels BUT will not send MIDI clock.

Sometimes this is helpful if you want to change presets on a device but you don't want it to sync to the clock.

SET DIP SWITCHES to ON-ON-ON (MJ1) or ON-ON-ON-OFF (MJ2 / MJ3).

If you have a pedal with a remote tap tempo input such as a Boss DD-7, JHS Panther Cub, Matthews Conductor, etc. and you'd like to send taps or clock signal to it, you can use the MultiJack as a remote-controlled tap tempo switch.

SET MJ1, MJ2, and / or MJ3 TO T-NC (for Boss devices) or T-NO (for most other devices)

SET 1 CH, 2 CH, or 3CH TO ABC

SET DIP SWITCHES to OFF-OFF-OFF (MJ1) or OFF-OFF-OFF-ON (MJ2 / MJ3).

If you're connecting a Boss pedal, you should set the MultiJack to N-C. Most other pedals require it set to the default N-O.

Strymon pedals with TAP functionality on their EXP jacks (Deco, DIG, Flint) require the use of a cable with a pull-up resistor - check the Disaster Area site for more info.

Strymon pedals that have an aftermarket / added tap jack may generally use a standard mono / TS cable.

If you would like to use the MultiJack to connect a tap tempo footswitch or expression pedal, the configuration is the same as the standard Expression input jack. Be sure to set the DIP switches to ON-ON-ON (MJ1) or ON-ON-ON-OFF (MJ2 / MJ3).

If you have an amplifier with channel switching, or reverb / tremolo footswitch inputs, you can use the MultiJacks to control these functions.

SET ONE DEVICE (choose any from DevA, DevB, etc.) to MULTIJACK.

Set MJ1, MJ2, and / or MJ3 to TOGG

SET DIP SWITCHES TO OFF-OFF-OFF (MJ1) or OFF-OFF-OFF-ON (MJ2 / MJ3).

Now you can enter the Device menu, tap over to the device you set as MultiJack, and the A, B, C buttons will toggle their respective MultiJacks on and off. MJ1 (red) = A, MJ2 (white) = B, and MJ3 (blue) = C. Set them the way you like and save your presets as normal. When you load that preset again, your amplifier or other device will switch back to the way you had it set previously.

15. USB MIDI and USB Host

The DMC-3XL / DMC-4 Gen3 are equipped with a 5-pin USB Mini-B connector on the back panel. While we do use it for firmware update, that's not a very exciting option. Let's take a look at the *cool* things you can do with the DMC USB port!

USB HOST (default)

The DMC Gen3 comes programmed to use the USB port as a HOST interface from the factory. What does that mean? Simply put, if you connect a USB MIDI device to the USB port using our gHOST Adaptor Cable, the DMC will try to talk to it. If it's compatible, then we can send and receive data from the device and you can control it just like any other device.

Some of the most useful devices that we can control are the Zoom MultiStomp series - specifically the MS-50G, MS-60B, and MS-70CDR. Unfortunately the MS-100BT does not have a USB port and so we can't control it.

To connect and control the MultiStomps, you first have to set up DevA as ZOOM MultiStomp in the Setup Menu. While you're in there, make sure that USB is set to HOST, and save to exit. Once you have configured the device and the USB mode, you can connect the MultiStomp USB port to a standard USB A to Mini-B cable, and attach that to the gHOST Adaptor. Plug the gHOST Adaptor into the DMC Gen3 and that's it! You can now control the Zoom pedal just like any other pedal. Their MIDI support is limited, but you can change presets and engage the tuner.

USB MIDI

If you want to control your PC / Mac / iPad with your DMC, or if you want to send out MIDI from one of those devices to the rest of your pedalboard, you can instead go to Setup and set USB to MIDI. Once you save and exit, the USB port on the DMC Gen3 will function as a USB MIDI device instead of a USB Host. Connect your computer or tablet to the DMC USB port using the appropriate cable and the DMC Gen3 will show up as a USB MIDI device. Any data your computer sends to the DMC Gen3 will be retransmitted out through its 5-pin MIDI port to your pedalboard, and any commands you execute on the DMC will transmit back to the computer / tablet.

16. MIDI System Exclusive Data Transfer (new in v1.02a)

The DMC-3XL / DMC-4 Gen3 is equipped with a simple MIDI System Exclusive (SysEx) data transfer function, designed to allow the user to back up and restore the state of the Gen3 controller.

We recommend the use of SendSX (PC) or SysEx Librarian (Mac) for recording and restoring SysEx transfers.

WARNING! Sending data from the Gen3 to a computer is 100% safe. Sending data from a computer to the Gen3 WILL overwrite its presets and configuration, and may result in data loss or setup corruption. Proceed with caution!

Instructions for backing up data to a computer: (SysEx Dump)

1. Power the Gen3 on and enter Setup by holding the lower left and lower right buttons shortly after boot.
2. Navigate to the DUMP menu in setup, and enter it by pressing the mode button.
3. Use the left or right buttons to select the type of data transfer you would like to perform. DO NOT start the transfer at this time.
 - ALL - transfer all presets including BYPASS and FAVE, transfer full configuration
 - CFG - transfer full configuration
 - PRST - transfer presets including BYPASS and FAVE, from preset 1 through the highest preset used in setup.
4. Once you have selected the type of transfer, connect the Gen3 to your computer running the appropriate SysEx software. If you have installed the USBMIDI firmware, you may connect the Gen3 directly to the computer using a USB cable. If you have installed the USBHOST version, you should connect using a standard 5-pin MIDI cable and MIDI interface.
5. Start the SysEx software on your computer and select the correct MIDI interface in its preferences or setup menu. If you have connected the USBMIDI version of the Gen3 to your computer, it should show up here as "DISASTER G3 MIDI."
6. Prepare the SysEx software to receive a SysEx transfer, consult with the user guide for your software for more details.
7. Press the mode button on the Gen3 to start the transfer. The display will update to alert you to the transfer status.
8. This should result in a data transfer being sent to your computer, which will record the data in a file.
9. When the transfer is complete, you can use the right and left buttons to select other transfer types. Pressing the mode button with a transfer type selected will perform additional transfers. To exit the DUMP menu, press the left or right buttons until the display is blank, then press the mode button to exit.


Instructions for restoring configuration and presets from a computer: (SysEx Load)

1. Power on and connect the Gen3 to your computer running the appropriate SysEx software. If you have installed the USBMIDI firmware, you may connect the Gen3 directly to the computer using a USB cable. If you have installed the USBHOST version, you should connect using the Disaster Area Designs MIDI-Y Cable and to your MIDI interface.
2. Start the SysEx software on your computer and select the correct MIDI interface in its preferences or setup menu. If you have connected the USBMIDI version of the Gen3 to your computer, it should show up here as "DISASTER G3 MIDI."
3. If you are using the 5-pin MIDI port to update, set up your SysEx software to allow 500 milliseconds (0.5 seconds) between SysEx messages. This will ensure that the DMC can process and respond to the messages correctly. If you are using the USB port / USBMIDI to update, this is not necessary but will not hurt.
4. Prepare the SysEx software to send a SysEx transfer, consult with the user guide for your software for more details.
5. Ensure that no other MIDI devices are connected to the Gen3, to avoid possible data corruption.
6. Initiate the data transfer from your computer. The Gen3 will show "Xabc" on its display, where "abc" is replaced by the number of the preset it is receiving. The display names and LEDs may also change while this process occurs. If the DMC receives a SysEx message with Config data, the display will indicate this as well, and will prompt you to restart the controller once it is finished. Note: Failure to restart the controller after receiving a SysEx Config message may result in the controller operating incorrectly.

17. Access / DAW control mode

We've added in a new mode - ACCESS. This mode is backwards compatible with the older DMC-6D controllers running the "Ableton" firmware, as well as with the Looptimus and Ability controllers. It's designed for launching clips from DAW hosts such as Ableton Live.

Access Mode Controls:



Each button sends one MIDI note. Six notes are available in each bank.

Hold the Up or Down buttons to move to the next or previous bank. Tap a button to activate that bank and send the corresponding note.

The controller note values start at 0 (C-2) and end at 125 (F8). You may use the MIDI assignment page in Ableton to map these button values to almost anything!

Use the ACCS item in the DMC setup menu to select the MIDI channel that will be used to send these messages. We recommend selecting a channel that your other devices are not using, such as channel 15.

18. Setup Mode

Setup Mode allows you to configure every aspect of your DMC Gen3 Controller. Please refer to Section 4 for details on entering and navigating Setup Mode.

SETUP PARAMETERS:

PRST - Preset Mode

Sets the number of available preset banks
Range: 0-63 banks

DEV - Number of Connected Devices

Sets the number of connected MIDI devices
Range: DevA (one device) - DevF (six devices)

DevA / DevB / DevC - Device Control selection DevD / DevE / DevF

Please consult the Device Driver list at the end of this manual for a detailed description of the supported devices.

LOOP - Looper Device selection

Selects the device the DMC will use for looper control
Range: DevA - DevF
If the selected device does not support looper control, Looper Mode will display "OFF" when entered.

EXP - Expression Pedal input (black jack) configuration

OFF - disable expression pedal input jack
EXPR - expression pedal
LPLV - looper volume level
SPLT - split expression, sends looper volume level in looper modes and expression in all others
TAP - tap tempo footswitch input
LATC - latching freeze / hold footswitch input
FAVE - favorite preset load / save footswitch input
BANK - advance to the previous mode
MIDI - send MIDI from expression pedal port

E CH1 / E CH2 - Expression Pedal input channel selection

A B C Expression Pedal enable / disable
D E F Expression Pedal enable / disable
If the location shows as zero, the controller will not transmit expression or looper level on that channel
If all three locations show as zero, no expression will be sent

MJ1 / 1CH - MultiJack 1 (RED) configuration

MJ2 / 2CH - MultiJack 2 (WHITE) configuration

MJ3 / 3CH - MultiJack 3 (BLUE) configuration

Please refer to Section 13 for MultiJack details

ROLL - Optional side roller configuration

OFF - disable expression roller, this should be selected if no roller is installed
EXPR - expression pedal
LPLV - looper volume level
SPLT - split expression, sends looper volume level in looper modes and expression in all others

R CH - Optional side roller channel selection

A B C Side Roller enable / disable

If the location shows as zero, the controller will not transmit expression or looper level on that channel

If all three locations show as zero, no expression will be sent

EDSP - Expression Pedal Display

d ON - Changes to the expression pedal, side roller, and MultiJack will be shown on the display briefly.

Expression Pedal will be prefixed with "E," Roller with "R," and MultiJack with "J."

d OFF - no expression values will be displayed

T FS - Tap / Down Footswitch behaviour

Sets the operation of the Tap / Down footswitch on DMC-6, Bank Down footswitch on DMC-8

pB dT - Bank down in Preset Mode, Tap in Device Mode

pT dT - Tap in both modes (default for DMC-6)

pB dB - Bank down in both modes (default for the DMC-8)

pt dB - Tap in Preset mode, Bank down in device mode.

CLK - Tap and Clock mode configuration

Refer to Section 10 for more details

t OFF - Tap and Clock modes are disabled.

t TAP - TAP TEMPO mode.

t CLK - PRESET CLOCK mode.

t TC - GLOBAL CLOCK mode

TCH1 / TCH2 - Tap Tempo channel selection

A B C Tap Tempo Pedal enable / disable

D E F Tap Tempo Pedal enable / disable

If the location shows as zero, the controller will not transmit tap tempo commands to that channel. Please note that MIDI clock will be sent to all devices regardless of this setting if clock is enabled

T DP - Tap and Clock Decimal Point configuration

0.5 - Clock may be set in 0.5 bpm increments

1.0 - Clock may be set in 1.0 bpm increments

T LEN - Tap Tempo output pulse length

0-6 Set higher for devices requiring a longer tap pulse (Walrus, Keeley, Echoplex Delay)

T CH1 - Tap Tempo MIDI Channel selection

TCH2

A B C Tap Tempo enable / disable

D E F Tap Tempo enable / disable

If the location shows as zero, the controller will not transmit tap tempo MIDI CC level on that channel

If all three locations show as zero, no tempo will be sent. **NOTE: this setting has no effect on MIDI clock!**

FAVE - FAVE configuration (DMC-8 only)
 OFF - FAVE is disabled, this should be selected if using a DMC-6 Gen3
 TAP - FAVE functions as tap tempo footswitch
 LATC - FAVE functions as latching freeze / hold footswitch
 FAVE - FAVE loads and saves the Favorite preset
 TUNE - FAVE activates the tuner on supported devices
 BANK - FAVE advances to the previous mode

F CH1 - FAVE channel selection

F CH2

A B C Favorite Program enable / disable
 D E F Favorite Program enable / disable
 If the location shows as zero, the controller will not send program changes on that channel
 If all three locations show as zero, no program changes will be sent.

DBRT - Display Brightness setting

0 - 9 - Sets display and LED brightness

HOLD - Button Hold Time setting

Controls the amount of time needed to activate the hold functions of the foot switches.
 Ranges from 0 (disabled) to 3750 milliseconds.
 Default is 1000 milliseconds (1 second)

InCH - MIDI input receive channel

1-16 - Sets channel that the DMC will use to respond to incoming MIDI commands

ACCS - Access Mode MIDI channel

0-16 - Sets the channel that the DMC will use to send data in Access Mode. Set to 0 to disable Access Mode.

NAME - Preset Name Display

OFF - no names will display, only preset numbers
 FOUR - the first four characters of the name will display
 SCRL - the preset name will scroll when loaded, then the preset number will display
 SCRL4 - the preset name will scroll when loaded, then the first four characters of the preset name will display.

BNAM - Bank Name Display

OFF - no names will display, only bank numbers
 FOUR - the first four characters of the bank name will display
 SCRL - the bank name will scroll when loaded, then the preset number will display
 SCRL4 - the bank name will scroll when loaded, then the first four characters of the bank name will display.

USB - USB Mode Configuration

MIDI - USB port will function as a MIDI interface when connected to a PC, Mac or iPad (using Camera Connection Kit.)

HOST - USB port will function as a USB HOST, allowing the user to control a USB MIDI device (requires Disaster Area gHOST Adaptor Cable).

PROT - Memory Protection

OFF - memory protection disabled. The user may edit and save presets, preset names, or bank names.
 ON - memory protect enabled. Presets, preset names, or bank names.

DUMP - SysEx Data Dump
PLEASE REFER TO SECTION 16.

FACT - Factory Reset

CFG - all setup menu values are reset. Presets and names are not affected.
 PRST - presets are reset. Names and setup values are not affected.
 NAME - preset names are reset. Presets and setup values are not affected.
 ALL - all values are reset.

SUGGESTED ACCESSORIES

DISASTER AREA RIGHT-ANGLE MIDI CABLES



Space-saving metal plugs rotate to eight different positions, making this cables ideal for your tight pedalboard setup.

DISASTER AREA MULTIJACK CABLES



MJ-CBA	MultiJack to Chase Bliss Audio
MJ-5P	MultiJack to 5-pin MIDI
MJ-STT	MultiJack to Strymon EXP / Tap Tempo

DISASTER AREA MIDI-Y CABLE

Pro-quality Y-cable allows for MIDI input and output from the Gen3 MIDI port.

DISASTER AREA EXPANDER SWITCH

Robust and tiny two-button footswitch connects to MultiJack 2 for bank up / down, remote tap + favorite, or looper controls.

DMC / DPC GEN3 SUPPORTED DEVICES

How to use this table:

We've listed the device drivers that are installed in your Gen3 controller below. Each driver has preset values for all of the various items the controller can access, so that you don't need to be a MIDI expert to use the controller!

We've listed the MIDI controller numbers that we send, in case you want to map them to something else or are trying to match up an unsupported device.

If you're not sure about a device you're using, we recommend you try **General MIDI** or **General MIDI No Bypass**. These drivers will allow you to send MIDI programs 0-127, which should support 99% of the devices on the market. If your device doesn't have 128 presets, then the upper range of the controller will be ignored by your device.

We add new devices all the time, so if you've got something that has special features not yet supported please contact us!

Manufacturer	Device	Menu Name	Expression	Tuner	Looper	Notes
NONE	General MIDI	Gen MIDI GMID	CC7	CC69	NO	Sends PC 0 instead of bypass CC
Strymon	Timeline	Timeline TIME	CC100	NO	YES	LTC sends command for infinite delay
Strymon	Mobius	Mobius MOBI	CC100	NO	NO	
Strymon	BigSky	BigSky BSKY	CC100	NO	NO	LTC sends command for freeze / infinite
Chase Bliss	ALL	ChasBliss CBA	CC100	NO	NO	
Boss	DD-500, MD-500, RV-500	DD-500	CC16	NO	YES	Map MIDI CC to TAP TEMPO or use MIDI clock
Empress	Reverb	Empress Reverb EMPR	CC10	NO	NO	Must enter Advanced Config mode on pedal to configure for MIDI
Empress	EchoSystem	Empress EchoS EECO	CC10	NO	NO	Must enter Advanced Config mode on pedal to configure for MIDI
Empress	Tremolo2	Empress Trem2 EMPT	CC10	NO	NO	Must enter Advanced Config mode on pedal to configure for MIDI
Source Audio	Neuro Hub / SoundBlox Hub	Source Audio HUB	NO	NO	NO	Configure using Hub Manager to set Hub MIDI channel
Source Audio	Nemesis / Ventriss	Nemesis Dely NEMS	CC100	NO	NO	
Line 6	M5	Lin6 M5 L M5	CC1	CC69	NO	Set AutoSave to OFF to avoid corrupting presets
	M9	Lin6 M9 L M9	CC1	CC69	YES	Set AutoSave to OFF to avoid corrupting presets
	M13	Lin6 M13 LM13	CC1	CC69	YES	Set AutoSave to OFF to avoid corrupting presets
Electro-Harmonix	HOG2	EHX HOG2 HOG2	CC4	NO	NO	
Pigtronix	Echolution 2 (all versions)	Echolutn ECL2	CC4	NO	NO	
Alexander	Neo Series / Super Series	Alexandr ALEX	CC100	NO	NO	
Panda Audio	Future Impact	F. Impact F IM	CC7	NO	NO	
Free the Tone	Flight Time	Flight Time FLTM	CC81	NO	NO	

Manufacturer	Device	Menu Name	Expression	Tuner	Looper	Notes
DigiTech	Whammy V Classic Mode	Wham Classic WHM1	CC11	NO	NO	
DigiTech	Whammy V Chords Mode	Wham Chords WHM2	CC11	NO	NO	
Zoom	MS-50G MS-60B MS-70CDR	MultiStomp ZOOM	No	CC74	NO	Set USB=HOST in Setup. Configure DevA as ZOOM. Use gHOST Adaptor Cable.
Atomic	AmpliFIRE	AmpliFIRE ATOM	CC22	NO	NO	Sends CC81 for LTC
NONE	MultiJack Relay Output	MultiJack JACK	NO	NO	NO	Special - does not send MIDI, controls the relay output on the MultiJack(s). Set DIP switches to ON-ON-ON or ON-ON-ON-OFF (DMC-6/8)
Hologram	Dream Sequence	Hologram DREM	NO	NO	NO	
Meris	Ottobit Jr Polymoon Enzo	Ottobit OTTO	CC4	NO	NO	Use Meris setup mode to assign EXP port to MIDI
Meris	Mercury7	Mercury7 MRC7	CC4	NO	NO	Use Meris setup mode to assign EXP port to MIDI
Boss	SY-300	BOSS SY-300 SY-3	CC7	CC24	NO	
GFI System	Specular Tempus	GFI SPECULAR GFI	NO	NO	NO	
NONE	MIDI Notes	MIDI Notes NOTE	CC7	CC69	NO	Special - sends MIDI note of the selected value when preset is loaded.
NONE	General MIDI (no bypass)	GenMIDINoByp GM-2	CC7	CC69	NO	Like General MIDI, but does not send PC or CC when in bypass. Used for "always on" devices.
Line 6	HX Effects	HX Effects HXFX	CC1	CC68	YES	Must enable looper block to use looper controls.
Line 6	HX Stomp	HX Stomp H ST	CC1	CC68	YES	Must enable looper block to use looper controls.
Bondi	Art Van Delay	Art VanDelay ARTV	NO	NO	NO	Defaults to channel 10 or channel 3 - reconfigure to use
Dr. Scientist	The Atmosphere	Atmosphere ATMO	NO	NO	NO	Accesses factory presets 1-16 and user presets 1-16.